


Product Instruction P21-19




Differential Pressure Transmitter Type BK

LIST OF ILLUSTRATIONS

Figure	<u>Title</u>	<u>Page</u>
1	Mounting Dimensions, Type BK7 Transmitter	4
2	Mounting Dimensions, Type BK8 and BK9 Transmitter	5
3	Supply Air Connections	5
4	Instrument Piping Selection Chart, Based on Pressure Piping Code, ANSI B31 1 0	6
5	Connecting Piping for Open or Closed Tank, Noncondensing Atmosphere	7
6	Connecting Piping for Liquid Measurement	7
7	Connecting Piping for Closed Tank, Condensing Atmosphere	8
8	Connecting Piping for Steam Measurement	8
9	Connecting Piping for Gas Measurement	9
10	Commercial Manifold Piping	9
11	Location of Vent Valves	10
12	Diaphragm Pressure Test	14
13	Alignment of Sealing Diaphragm	15
14	Vane Nozzle Alignment	16
15	Typical Calibration Setup	19
16	Measuring Diaphragm, Type BK7 Transmitter	20
17	General Assembly, Type Bk Transmitter	22
18	Booster Relay Adjustment	27
19	Booster Relay Calibration Block, Part No. 5320549-1	27
20	Suggested Calibration	28
21	Schematic of Type BK Differential Pressure Transmitter	29
22	Schematic of Booster Relay	30
23	Transmitter Range Charts	33
24	Parts Drawing P21 27, Type BK Differential Pressure Transmitter	35
25	Parts Drawing P21 28, Internal Mechanism for Type BK Differential Pressure Transmitter	36
26	Parts Drawing P21 30, Type BK7 Measuring Diaphragm Assembly	38
27	Parts Drawing P21 29, Type BK8 and BK9 Measuring Diaphragm Assembly	40
28	Parts Drawing P21 9, Booster Relay, Part No. 5324957-1	41

INDEX

	Page
INSTALLING THE TRANSMITTER	4
Unpacking	4
Mounting	4
Connecting Tubing and Piping	4
OPERATING THE TRANSMITTER	9
Placing Transmitter in Service	9
Removing from Service	10
ROUTINE SERVICING	11
Connecting Tubing and Piping	11
Blowing Down Connecting Piping	11
Flow Measurement	11
Level Measurement	11
Booster Relay	12
TROUBLESHOOTING	12
Disassembling the Transmitter	12
Replacing Measuring Diaphragm - Type BK7	13
Replacing Diaphragm Capsule - Type BK8 and BK9	13
Resetting Initial Output - Type BK8 and BK9	13
Replacing Restoring Bellows	14
Replacing Sealing Diaphragm	15
Replacing the Booster Relay	16
Replacing Booster Relay	16
Vane-Nozzle Alignment	16
Vane Spring Loading	16
Fault Correction Chart	17
CALIBRATING THE TRANSMITTER	19
Pre-Service Adjustments	19
Complete Calibration Procedures	20
Calibration Procedure Type BK7	20
Calibration Procedure - Type BK8 and BK9	24
Calibrating the Booster Relay	27
HOW THE TRANSMITTER OPERATES	28
Type BK Differential Pressure Transmitter	28
Suppression Spring	29
Booster Relay	29
REPLACEMENT PARTS	34
Spare Parts Kits	34
Ordering Individual Parts	34



NOTES

1 The curve representing the rating of the tubing selected must lie above the intersection of lines representing the actual expected maximum sustained temperature and pressure.

2 Tubing materials, dimensions and specifications are those of tubing stocked by Bailey Meter Company. In some cases larger sizes are recommended. Several commercial pipe sizes have been shown for convenience.

3 If other materials or sizes of wall thicknesses are used allowable working pressures must be calculated as provided for in the code.

4 Temperatures are instrument line fluid temperatures. In steam service tubing preceding blowdown valves shall be suitable for saturated steam temperature at the design main line pressure.

5 Copper tubing may be used in dead end steam or water service up to design pressures and temperatures shown by the dotted curves provided that the temperature within the lines for continuous service does not exceed 406°F.

6 Pressure and/or temperature may exceed the normal design conditions occasionally provided the pressure does not exceed the allowable value for the temperature involved by more than:

- (1) 15% during 10% of the operating period
- (2) 20% during 1% of the operating period

7 The recommended minimum wall thickness for socket welded tubing is .065".

8 Tubing wall thicknesses are not calculated to provide additional thickness that may be required for mechanical strength. Tubing should be continuously supported in conduit trays or channels.

FIGURE 4 Instrument Piping Selection Chart, Based on Pressure Piping Code, ANSI B31.1.0

Type BK Transmitter




FIGURE 5 Connecting Piping for Type BK Transmitter Open or Closed Tank, Noncondensing Atmosphere




FIGURE 6 Connecting Piping for Liquid Measurement




FIGURE 7 Connecting Piping for Type BK□□□2 Closed Tank, Concensing Atmosphere





FIGURE 8 Connecting Piping for Steam Measurement

Type BK Transmitter




NOTES

- GENERAL
MOUNT TRANSMITTER ABOVE PRIMARY ELEMENT CONNECTIONS
MAKE PRIMARY ELEMENT UNITS AS LOW AS POSSIBLE
FLANGE IN HORIZONTAL FLOW
ALL HORIZONTAL CONNECTION LINES SHOULD SLOPE AT
LEAST ONE INCH PER FOOT DOWNWARD TO MAIN LINE
A 1/2 VALVES STEMS UP OR AT SLIGHT ANGLE - TAGGED
FOR CLEARANCE
B ADDITIONAL SET OF VALVES REQUIRED FOR LONG CONNECTING LINES
OR WHEN DESIRABLE TO MOUNT UNIT AT FLOOR LEVEL
TO PERMIT SERVICING
C EQUALIZING VALVE
D) 2 2 SUPPORTING P.P.E. (NOT BY B.M.CO.)
E) 2 NIPPLES TO FLANGE OR P.P.E. PRESSURE TAP

FIGURE 9 Connecting Piping for Gas Measurement

OPERATING THE TRANSMITTER



NOTES

- A 1/2 VALVES OPEN ONLY AFTER
LINES HAVE BEEN REFILLED WITH
CONDENSATE AFTER BLOWDOWN
B SEE FIGURES 5 THRU 9
C MAN FOLD VALVE 2" SPACING

FIGURE 10 Commercial Manifold Piping

PLACING TRANSMITTER IN SERVICE

WARNING: Do not subject Type BK8 or BK9 Transmitter to pressure greater than 1500 psig. Isolate Transmitter from system during hydrostatic test of piping requiring over 1500 psig. Pressures in excess of rating may damage the force beam sealing diaphragm.

1. Make certain that all connecting tubing is correctly installed (Figures 5 thru 9) and that all valves are closed.
2. Apply supply air to Booster Relay on Transmitter.

3. Open equalizing valve (C) in pressure line to Transmitter (Some level applications on open or closed tanks with noncondensing atmospheres may not use an equalizing valve. In this case, ignore reference to equalizing valve and LO pressure piping in following procedure).

4. If blowdown valves are installed:

a. Open one blowdown valve slowly. Allow to blow a sufficient length of time to clear line (usually not more than 15 seconds). Close blowdown valve.

b. Repeat step 4a with other blowdown valve.

5. If blowdown valves are not installed:

a. Disconnect connecting piping at HI and LO connections at Transmitter

b. Slowly open instrument valve in HI pressure line to Transmitter. Allow to blow a sufficient length of time to clear line (usually not more than 15 seconds). Close instrument valve in HI pressure line.

c. Repeat step 5b with valve in LO pressure line

d. Reconnect piping at HI and LO Transmitter connections.

6. If Transmitter measures steam flow, allow time for steam in connecting lines to condense and for connecting lines to reach normal operating temperature before proceeding to step 7.

7. Slowly open instrument valve in HI pressure line to Transmitter and allow pressure to build up on both sides of diaphragm capsule.

8. Liquid applications only crack vent valves V1 and V2 (1/4 turn to unseat) and allow trapped air to escape. Close vent valves. (See Figure 11 for location of vent valves.)

9. Booster output pressure should be 3 psi (27 or 15 psi for reverse action units. Type BK1112) Adjust zero adjustment (Fig 17) as necessary until output is correct

NOTE: On level applications with one side of diaphragm vented, Booster output pressure will not be 3 psi. Output pressure will be increased in proportion to head on high pressure connection

10. Slowly open instrument valve in LO pressure line to Transmitter

11. Close equalizing valve (C). Transmitter is now in service

REMOVING FROM SERVICE

1. Open equalizing valve (C) in pressure line to Transmitter

2. Close instrument valves in HI and LO pressure lines to Transmitter

3. Open vent valves V1 and V2, or 1c move plugs in bottom of diaphragm capsule

4. Turn off air supply to Booster Relay

5. Transmitter is now out of service




FIGURE 11 - Location of Vent Valves

Type BK Transmitter

ROUTINE SERVICINGCONNECTING TUBING AND PIPING

1. Keep all tubing and piping connections tight. Check tubing and piping for leakage while under pressure with a leak detecting solution.

2. Maintain a regulated air supply, free of dirt, oil and moisture to Booster Relay.

3. Periodically blow down connecting piping as outlined below

WARNING: Do not blow down lines into the Transmitter. Blowdown temperature may damage the Transmitter.

BLOWING DOWN CONNECTING PIPINGA. Flow Measurement

Follow the procedure below to blow down connecting lines if installation includes blow down piping.

1. Close instrument valves in HI and LO pressure lines to Transmitter and open equalizing valve.

2. Open one blowdown valve slowly to prevent sudden strain on connecting line. Allow a sufficient length of time to clear line (usually not more than 15 seconds is required). Close valve

3. Repeat step 2 with other blowdown valve

4. If Transmitter measures steam, allow time for steam in connecting lines to condense and to reach normal operating temperature before placing Transmitter in service.

5. Slowly open instrument valve in LO pressure line to Transmitter. Close equalizing valve. Slowly open instrument valve in HI pressure line. Transmitter should respond immediately.

Follow the procedure below to blow down connecting lines if installation does not include blowdown piping. Refer to Figures 5, 6, or 7 as applicable

1. Close instrument valves in HI and LO pressure lines to Transmitter and open equalizing valve.

2. Crack unions or fittings below instrument valves and bleed off pressure in diaphragm.

3. Disconnect connecting lines from instrument at unions or fittings on Transmitter manifold or connecting piping

4. Swing connecting lines away so blow down is not directed at Transmitter (If connecting lines cannot be moved easily temporarily add short lengths of tubing to direct blowdown away from Transmitter.)

5. Open one instrument valve slowly to avoid sudden strain on connecting line. Allow line to blow a sufficient length of time to clear line (usually not more than 15 seconds is required). Close valve

6. Repeat step 5 with other instrument valve.

7. If Transmitter measures steam allow time for steam in connecting lines to condense and reach normal operating temperature before placing Transmitter in service.

8. Reconnect connecting lines. Slowly open instrument valve in LO pressure line to Transmitter. Close equalizing valve. Slowly open instrument valve in HI pressure line. Transmitter should respond immediately.

B. Level MeasurementOpen or Closed Tank, Non-Condensing Atmosphere

1. Refer to Figure 5. Close instrument valve (E)

2. Open blowdown valve (F) slowly to prevent sudden strain on connecting line. Allow to blow a sufficient length of time to clear line (usually not more than 15 seconds is required). Close blowdown valve.

3. Slowly open shutoff valve (E). Transmitter should respond immediately.

Closed Tank Condensing Atmosphere

1. Refer to Figure 9. Close instrument valves (B) and open equalizing valve (C).

2. Open one blowdown valve (D) slowly to prevent sudden strain on connecting line. Allow to blow a sufficient length of time to clear line (usually not more than 15 seconds is required). Close blowdown valve.

3. Repeat procedure in step 2 for other blowdown valve.

4. Allow time for steam in connecting lines to condense (or refill manually thru filling plugs shown in Figure 9) and for connecting lines to reach normal operating temperature before placing Transmitter in service.

5. Slowly open shutoff valve (B) in low

pressure line (marked HI). Close equalizing valve (C). Slowly open shutoff valve in high pressure line (marked LO). Transmitter should respond immediately.

BOOSTER RELAY

1. Periodically inspect nozzle tip (Figure 17) and vane for deposits of oil, dirt, etc. Clean with a suitable solvent.

2. Periodically replace felt pad air filters as follows:

a. Turn OFF supply air to Booster Relay and disconnect supply air and output lines (Figure 3).

b. Remove wire mesh disc (Item 25, Figure 27) and felt pads (Item 27) with pick or similar instrument.

c. Replace felt pads. Replace wire mesh discs.

NOTE: When replacing mesh discs, make certain there is a disc under felt pad in supply connection.

d. Reconnect supply air and output lines to Booster Relay.

TROUBLESHOOTING

1. If Transmitter is inoperative or if operation is faulty, first check Transmitter calibration as outlined under 'Pre Service Adjustments', page 19. If correct output readings still cannot be obtained, proceed as follows (see Figure 17):

a. Visually inspect for any missing screws or broken parts at sealing diaphragm vane adjustment screw, spring pivot hinge and restoring bellows.

b. Check that all screws are tight. If any screws in areas around spring pivot hinge, tension strip, mounting feet, nozzle set screw, vane spacer, mounting plate, restoring bellows, and force beam are found to be loose, refer to 'Complete Calibration Procedures', page 20.

c. Check that when Transmitter is in operation, only contact between the force beam and restoring beam is at fulcrum.

If it is suspected that the Transmitter is mechanically defective or the Booster Relay is faulty, refer to 'Fault Correction Chart', page 17.

DISASSEMBLING THE TRANSMITTER

NOTE: Make certain Transmitter is disconnected from pressure source before removing and replacing diaphragm or diaphragm capsule.

Replacing Measuring Diaphragm Type
BK7 [] [] (Refer to Figures 16 and 26)

1. Remove pipe plug (25) from housing.
2. Insert 3/16 inch Allen wrench thru pipe plug hole and loosen (do not remove) connector clamp nut.
3. Remove Booster Relay
4. Remove mounting bolts (30) holding diaphragm assembly to pressure housing, and pull assembly away from housing.
5. Loosen and remove all diaphragm clamp bolts
6. Pry outer housing away from inner housing. (Use screw driver or similar instrument.)

NOTE: Gasket, diaphragm, and center assembly remain connected to inner housing. Do not damage parts during this operation.

7. Remove two hanger strap screws (Figure 16) holding diaphragm center hanger straps to inner housing (located at top of housing reach by folding down upper portion of diaphragm).
8. Pull gasket, diaphragm, and diaphragm to diaphragm center assembly. Force out nylon sleeves, and discard
10. Remove jam nut on diaphragm center assembly.
11. Remove damaged diaphragm. Insert new nylon sleeves in replacement diaphragm and install in center assembly. Align diaphragm as shown in Figure 16
12. Reassemble diaphragm assembly by reversing steps 3 thru 10 (see Table II, page 32, for torque values). Do not tighten connector clamp nut or replace pipe plug.
13. Repeat steps 7 thru 11 under 'Calibration Procedures Type BK7' on page 20 to correctly position connector
14. Perform calibration as outlined under 'Pre-Service Adjustments' on page 19.

Replacing Diaphragm Capsule - Type Bk [] []
and BK9 [] [] (Refer to Figure 27)

1. Remove pipe plug (8) from diaphragm assembly
2. Insert 3/16 inch Allen wrench thru pipe plug hole and loosen (do not remove) connector clamp nut
3. Remove four screws and bolts holding front housing to base housing. Remove front housing.
4. Pull diaphragm capsule assembly from base housing. (This assembly must be replaced as a unit; it cannot be repaired.) Remove and examine diaphragm housing seals (Item 4, Figure 27) replace if damaged

NOTE: This assembly must be replaced as a unit; it cannot be repaired.



5. Place diaphragm housing seals in position on new diaphragm capsule assembly. Insert diaphragm capsule assembly, with connector, between D-washer and force beam nut. Lightly tighten connector clamp nut allowing capsule unit to assume its own rotational position (see Figure 24).

6. Replace front housing and tighten nuts finger tight.
7. Loosen connector clamp nut and tighten mounting screws and nuts to torque specified in Table II on page 32.
8. Reset initial output of Transmitter as outlined under 'Resetting Initial Output' below.

Resetting Initial Output - Types BK8 [] []
and BK9 [] []

1. Apply supply pressure to Booster Relay of Transmitter.
2. Adjust output pressure to 3 psig by turning zero spring adjustment (Reset suppression spring nut if error exceeds 1 psi)

NOTE: Steps 3 and 4 may be omitted if previously performed during diaphragm capsule replacement



NOTES

APPLY THE FOLLOW NG PRESSURES FOR TEST NG

- (a) 60 PS G FOR TYPE BK7
- (b) 500 PS G FOR TYPE BK8 AND BK9 *

* CAUTION USE ONLY HYDRAUL C HEADS FOR H GH PRESSURE TEST NG

- 1 D APHRAGM MAY EE RUPTURED
- 2 O R RINGS N D APHRAGM CENTER MAY BE DEFECT VE.
- 3 SCREWS THROUGH NYLON NSERTS N D APHRAGM CENTER MAY BE LEAK NG A R

FIGURE 12 Diaphragm Pressure Test

3. Insert diaphragm capsule assembly with connector between D washer and force beam nut. Lightly tighten connector clamp nut (see Figure 27)

4. Install front or lower housing and tighten mounting nuts finger tight.

5. Loosen connector clamp nut, and tighten mounting nuts to torque specified in Table II on page 32.

6. Tighten connector clamp nut to torque specified in Table II. (Output of Transmitter must remain within 0.5 psig limit during this operation. If not loosen connector clamp nut and retighten until output remains constant.) If output still shifts remove front housing, pull out and rotate capsule 180° and repeat above procedure

7. Pressure test assembly as outlined in Figure 12 following listed precautions

8. Calibrate Transmitter as outlined under Pre Service Adjustments, page 19

Replacing Restoring Bellows (Figure 25 Item 28)

1. Remove mounting screws (18) holding Booster Relay to mounting plate (12). Remove Relay (Figure 24)

2. Remove screw holding manifold clamp (25) to mounting plate (45)

3. Loosen set screw (56) holding bellows to restoring beam.

4. Remove screws holding spring and bellows support (20) to mechanism frame

5. Lift spring and bellows support, with restoring bellows attached from mechanism frame.

6. Remove screw (24) holding bellows to support. Replace bellows (26).

7. Reverse steps 1 thru 6 to replace assembly (see Table II on page 32).

8. Calibrate Transmitter as outlined under Pre Service Adjustments on page 19

Type BK Transmitter




FIGURE 13 - Alignment of Sealing Diaphragm

Replacing Sealing Diaphragm
(Figures 13 and 25)

- 1 Remove pipe plug in bottom of high pressure side of housing
2. Insert 3/16 inch Allen wrench into housing and unclamp capsule from mechanism.
3. Remove Booster (insure 0 rings remain on manifold face of Booster).
- 4 Loosen flat head screw holding air-line manifold clamp (25).
5. Remove four socket head screws (44) holding spring support assembly (39) to force beam (43).
6. Remove nozzle vane (54), clamp plate (55) and vane spacer (53) as a subassembly by removing two No. 4-40 screws holding vane spacer (53) to nozzle bracket assembly (47).
- 7 Remove nozzle air line assembly (50) by loosening No. 4-40 screw in nozzle clamp block (51).
- 8 Remove three socket head screws (13) and (11), holding mechanism frame (4), to mounting plate (45). Lift off frame subassembly
9. Remove four socket head screws (40), holding tension strips, etc. to base Remove tension strip assemblies (42)
10. Remove vane and bracket subassembly from force beam Force beam subassembly

cannot be removed unless capsule or diaphragm assembly is removed:

- a. For Type BK□□1 and BK□□2 units Remove four bolts holding housing together. Remove capsule.
- b. For Type BK□□0 units. Remove four socket head screws holding diaphragm assembly to housing block. Remove diaphragm assembly.
11. Remove force beam connecting clamp nut (16) and washer (15) in Figure 27.
- 12 Remove force beam subassembly
13. Grip one tension strip mounting ear (on force beam) in vise, and unscrew force beam nut (29 in Figure 26; 14 in Figure 27).
14. Remove sealing diaphragm and replace with new part
15. Replace and tighten force beam nut.

NOTE: Alignment of parts is important (see Figure 13). Sight thru pair of holes in mounting plate to maintain alignment of tension strip mounting surfaces on upper section of force beam. Correct tightening torque is important (see Table II on page 32)

16. Reverse above procedure to reassemble unit Do not tighten connector clamp nut.
17. Perform Pre-Service Adjustments as outlined on page 19

REPLACING THE BOOSTER RELAYReplacing Booster Relay (Figure 24)

1. Remove Transmitter from service as outlined under 'Operating the Transmitter'.
2. Remove two screws (Item 18, Figure 24) securing Booster Relay to Transmitter housing.
3. Install new Booster Relay unit on Transmitter housing using screws used in step 2.
4. Recalibrate Booster Relay as outlined under 'Calibrating the Booster Relay', page 27, before returning to service.

Vane Nozzle Alignment (Figure 14)

1. Check that vane is parallel to plane of nozzle tip as follows:

- a. With Booster Relay at balance, press lightly with pointed instrument above and below nozzle tip.
- b. If pressure at either point produces the effect shown in Sketch B (Figure 14), either (1) vane is not parallel to nozzle tip or (2) there is a burr on nozzle tip.
- c. If vane is not parallel to nozzle tip, bend vane slightly. If burrs present, rub fine emery cloth lightly across nozzle tip.

2. With zero differential and no load on suppression spring, turn vane adjustment




FIGURE 14 Vane Nozzle Alignment

- screw (Figure 17) until output is 3 psig.

3. Perform 'Pre Service Adjustments', page 21.

Vane Spring Loading (Figure 19)

1. With no supply pressure and vane adjustment screw not touching vane, vane should contact nozzle with a tension of 12 to 15 grams. (Do not back off vane adjustment screw to make this check.)
2. If vane does not contact nozzle, move vane, bend vane spring, replace vane, and check.
3. When correct relationship is obtained, turn vane adjustment screw (zero differential) until output is 3 psig.
4. Perform 'Pre Service Adjustments', page 19.


Type BK Transmitter

Fault Correction Chart

TRANSMITTER FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
<p>1. Output from Booster Relay does not increase to about full supply pressure when force beam is pushed toward restoring bellows.</p>	<p>a. Supply and output connections to Booster Relay are incorrect.</p> <p>b. Dirty nozzle orifice in Booster Relay.</p> <p>c. Vane - nozzle relationship incorrect.</p> <p>d. Burr on nozzle tip.</p> <p>e. Nozzle alignment incorrect.</p> <p>f. Nozzle air line leaking.</p> <p>g. Booster calibration incorrect.</p> <p>h. Vane spring loading incorrect.</p>	<p>a. Connect as shown in Figure 3</p> <p>b. Depress nozzle orifice plunger.</p> <p>c. Refer to "Vane-Nozzle Alignment", page 16.</p> <p>d. Rub a fine emery cloth lightly across nozzle tip to remove possible burr</p> <p>e. Refer to "Vane-Nozzle Alignment", page 16.</p> <p>f. Check that Booster is mounted securely.</p> <p>g. Calibrate Booster (see page 27).</p> <p>h. Refer to "Vane Spring Loading", page 16.</p>
<p>2. Output from Booster Relay does not drop to zero when force beam is pushed away from restoring beam causing vane to move away from the nozzle.</p>	<p>a. Supply and output connections to Booster Relay are incorrect.</p> <p>b. Dirty nozzle.</p> <p>c. Nozzle air line is pinched off.</p> <p>d. Booster Relay orifices dirty.</p> <p>e. Booster calibration incorrect.</p>	<p>a. Connect as shown in Figure 3</p> <p>b. Check nozzle tip and clean with a suitable solvent.</p> <p>c. Check visually. Reposition as necessary.</p> <p>d. Depress nozzle orifice plunger.</p> <p>e. Calibrate Booster (see page 27).</p>
<p>3. Output readings are non linear</p>	<p>a. Leakage from output line or restoring bellows.</p> <p>b. Incorrect vane alignment</p> <p>c. Dirty nozzle orifice in Booster Relay.</p>	<p>a. Replace line or bellows.</p> <p>b. Refer to "Vane Nozzle Alignment", page 16</p> <p>c. Depress nozzle orifice plunger</p>

FAULT CORRECTION CHART (Continued)		
TRANSMITTER FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
3 (Continued)	<p>d. Booster calibration incorrect.</p> <p>e. Diaphragm capsule or measuring diaphragm cracked, capsule im properly installed, or silicone fluid is leaking.</p> <p>f. Zero adjusting nut posi tioned so that zero spring is fully compressed dur ing normal operation.</p>	<p>d. Check Booster calibra tion (see page 27)</p> <p>e. Replace capsule or dia phragm as outlined un der 'Replacing Dia phragm Capsule', or 'Replacing Measuring Diaphragm', page 13.</p> <p>f. Calibrate Transmitter as outlined on page 20 or 24, as applicable.</p>
4. Output readings indicate hysteresis.	<p>a. Vane adjustment screw is rough.</p> <p>b. Booster calibration in correct.</p> <p>c. Damaged diaphragm cap- sule, diaphragm, con nector, or sealing dia phragm.</p>	<p>a. Smooth vane contact surface of screw with very fine sand paper</p> <p>b. Check Booster cali bration (see page 27).</p> <p>c. Replace as outlined under Replacing Meas- uring Diaphragm Cap sule', or "Replacing Sealing Diaphragm", page 15.</p>
5. Transmitter output indi cates erratic operation.	<p>a. Air leakage.</p> <p>b. Moisture or oil deposits in air passages.</p>	<p>a. Tighten or replace parts as necessary.</p> <p>b. Clean orifices with suitable solvent.</p>
BOOSTER FAULT	PROBABLE CAUSE	CORRECTIVE ACTION
1. Booster Relay output pres sure does not immediately increase when flow of air from nozzle is blocked.	<p>a. Clogged nozzle orifice.</p> <p>b. Leakage around sections of Booster casing.</p> <p>c. Dirty niters (see Figure 27).</p> <p>d. Booster calibration incorrect.</p>	<p>a. Depress nozzle orifice plunger.</p> <p>b. Replace Booster Relay.</p> <p>c. Remove and replace filters as outlined un der Routine Servie ing , page 11.</p> <p>d. Check Booster cali bration (see page 27).</p>

Type BK Transmitter



NOTES

1. USE ONLY MANOMETERS REQUIRED FOR MAXIMUM INSTRUMENT DIFFERENTIAL HEAD READING
2. FOR GREATER SENSITIVITY (LOW MAXIMUM DIFFERENTIAL) USE INCLUDING WATER MANOMETER
3. FOR Piping SPECIFICATIONS SEE INSTRUCTION SECTION 6 B INSTRUMENT CONNECTION DIAGRAM
4. SEE CALIBRATION INSTRUCTIONS IN SECTION 7 FOR DETAILED INSTRUCTIONS
5. TUBING FROM TRANSMITTER TO GAGE MUST BE AT LEAST 5' LONG
6. IF OUTPUT PRESSURE DOES NOT STABILIZE ADD A VOLUME CHAMBER IN THIS LINE
7. FOR OPEN OR CLOSED TANK NON CONDENSING ATMOSPHERE MAKE CONNECTION TO THE SIDE OF DIAPHRAGM AND VENT TO THE SIDE OF DIAPHRAGM
7. FOR CLOSED TANK CONDENSING ATMOSPHERE MAKE CONNECTION TO THE SIDE OF DIAPHRAGM AND VENT TO THE SIDE OF DIAPHRAGM

FIGURE 15 - Typical Calibration Setup

CALIBRATING THE TRANSMITTER

PRE SERVICE ADJUSTMENTS

1. Connect Transmitter in calibration setup (Figure 15). Position Transmitter in same position as that of final installation. Connect accurate water manometer to measuring diaphragm as indicated

2. Connect accurate laboratory type pressure gage in Booster Relay output pressure line. Make required Booster supply connection. Remove cover from Transmitter.

3. Apply differential pressure (or suppression head) that should produce a 3 psig output. If Transmitter output is not correct, adjust as follows:

a. Adjust zero spring (Figure 17) if

error is less than 1 psi.

b. Adjust suppression spring nut (Figure 17) if error is greater than 1 psi.

4. Apply differential pressure (or suppression head) that should produce output of 27 psig (Type BK-2□□) or 15 psig (Type BK-1□□). If Transmitter output is not correct, adjust range adjustment screw (clockwise to decrease range) to correct value (Figure 17). To prevent damage to threads on screw, remove applied differential before making any major range adjustments. Minor adjustments with full differential pressure are permissible.

5. Repeat steps 3 and 4 above until Transmitter output pressures are correct.




FIGURE 16 - Measuring Diaphragm, Type BK7 Transmitter

6 Check linearity by applying pressure to diaphragm in 10% increments thru range of applied differential pressure. Transmitter output pressure should vary proportionally (10% change in applied differential should produce 10% change in Transmitter output 2.4 psi for Type BK□□□□, 1.2 psi for Type BK□□□□). If linearity of output pressure is not within acceptable limits (+0.12 psi for Type BK□□□□, ±0.06 psi for Type BK□□□□), proceed to step 7.

7. If in steps 1 thru 6 only minor adjustments have been made and calibration is satisfactory, place Transmitter in service as outlined under "Operating the Transmitter", page 9

If Transmitter cannot be calibrated or linearity of output pressure is not within acceptable limits, refer to Fault Correction Chart or to 'Complete Calibration Procedures' below.

COMPLETE CALIBRATION PROCEDURES

If the Type BK Transmitter cannot be calibrated as outlined under 'Pre Service Adjustments', or if Transmitter has been disassembled for parts replacement or repair, refer to the applicable 'Calibration Procedure' below.

Calibration Procedure - Type BK7

1. Connect Transmitter in calibration setup as shown in Figure 15. Do not connect pressure lines to diaphragm or apply air supply to Booster Relay at this time.

NOTE: Before continuing "Calibration Procedure", check Transmitter for damaged parts or obvious leaks. Insure that all bolts and screws are tight (see "Troubleshooting", page 12) Then proceed as follows.

Type BK Transmitter

2. Remove suppression spring (15 or 16, Figure 25) from Transmitter by removing five screws (23 and 24) holding spring and bellows support to mechanism frame and set screw (22) holding adjusting nut in spring and bellows support. Replace spring and bellows support.

3. Refer to Figures 25 and 26 Remove pipe plug in high pressure side of diaphragm housing. Insert Allen wrench and turn connector clamp nut one half turn to disconnect diaphragm capsule.

4. Set adjustable fulcrum (36) to scale reading on restoring beam which corresponds to required differential pressure range.

5. Apply air supply to Booster Relay.

6. Transmitter output pressure should be 3.0 psig. If not, turn zero spring adjustment (27) to obtain 3.0 psig output. If 3.0 psig pressure cannot be obtained:

a. Turn OFF supply air to Transmitter.

b. Turn zero spring adjustment (27) until fulcrum (36) just clears force beam.

c. Adjust center line of vane to coincide with vane adjustment screw by loosening screws (52) and positioning vane.

d. Adjust vane to be parallel to fulcrum surface with vane adjustment screw (37). Turn on supply air and readjust vane adjustment screw so vane is parallel to force beam and/or restoring beam. (Output pressure should be 3.0 psig; zero adjusting spring coils must not be touching.)

e. If above parallel relationship can not be attained, loosen screw in nozzle clamp block and reposition nozzle until beams are parallel. Repeat step (6d) to obtain 3.0 psig output.

7. Apply 2 psig to low pressure side of measuring diaphragm.

8. Manually move force beam to left (toward diaphragm assembly) so that vane moves about 1/8-inch away from end of nozzle. Hold in this position.

9. Tighten connector clamp nut and disconnect pressure to low pressure side of measuring diaphragm.

10. Check clearance travel of measuring diaphragm center assembly Turn off supply air and remove two pipe plugs in bottom of diaphragm housing. Remove snubbers if included in bottom ports. Manually move force beam in both directions; there should be equal travel of approximately 1/16 inch free motion of upper end of force beam from neutral position.

11. Turn on supply air. With zero differential on Transmitter, manually move force beam in one direction, release, and note output pressure from Booster Relay. Deflect beam slightly in opposite direction, release, and again note output pressure. These pressures should repeat. If pressures do not repeat, continue with step 12. If pressures are correct, proceed to step 20.

12. If repeatability is unobtainable, remove four screws holding spring support plate to force beam and check that upper ends of tension strips are free over dowel pins. File holes in tension strips, if necessary.

13. If repeatability still cannot be obtained, strap hangers within the diaphragm assembly may be twisted, causing misalignment of diaphragm center structure.

14. To check if diaphragm center assembly is canted within diaphragm housing, or center assembly clamp plates are touching over-pressure stops (refer to Figure 16):

a. Do not disconnect diaphragm center assembly (Figure 16) from Transmitter.

b. Loosen and remove all hex head screws from diaphragm assembly.

c. Use screw driver or similar instrument to pry outer housing away from inner housing; make separation between outer housing and adjacent gasket.

d. Apply pressure with one finger to upper and lower parts of clamp plates—check whether center assembly travels equal distance in each direction before hitting over-

pressure stops. As an alternate procedure, lay a straight edge across faces of diaphragm housing, and measure if distances from periphery of diaphragm clamp plates (Figure 16) to straight edge are about equal

15. If diaphragm center assembly is canted, peel back upper portion of gasket assembly and loosen two hanger strap screws. Reposition center assembly until equal clearances are obtained.

16. If clearances behind clamp plates (step d) appear equal:

a. Manually press center assembly against over pressure stops. Remove hanger strap screws; then, maintaining pressure on center assembly, check whether holes in hanger straps line up properly with holes in inner diaphragm housing.

b. If holes do not line up properly, twist has been made in hanger straps.





FIGURE 17 - General Assembly, Type BK Transmitter

If twist is slight, file holes in the hanger straps slightly to obtain proper alignment. If twist is too large to correct by this method, proceed with step 17 below.

17 Remove center assembly from Transmitter as follows:

a. Remove pipe plug (Figure 17) from pressure housing.

b. Insert Allen wrench thru pipe plug hole and loosen, but do not completely unscrew, connector clamp nut

c. Pull diaphragm center assembly and gaskets (Figure 17) from inner diaphragm.

18. To align hanger straps:

a. Loosen jam nut; then reposition hanger straps as shown in Figure 16. Tighten jam nut to torque of 20 ft-lb

b. Reassemble diaphragm center assembly to inner diaphragm housing, check alignment as outlined in step 14d, page 21. Install hanger strap screws.

19. Reassemble diaphragm assembly and reset output as outlined on page 21 in steps 7 thru 11.

20. Turn OFF air supply to Booster Relay.

21. Remove five screws holding spring and bellows support to mechanism frame and bellows.

22. Add suppression spring. Lock nut on one end of threaded spring should be tightened to fix one end of spring to spring support assembly. Slots in guide bar on suppression spring should be parallel to base plate.

23. Add suppression nut (Item 14 or 19, Figure 25) and replace spring and bellows support plate. Insure that pins are not misaligned with slots in guide bar on suppression spring.

24. Turn ON air supply.

25. Apply minimum differential pressure (including suppression) to appropriate side of measuring diaphragm capsule and adjust suppression spring tension to obtain desired output value (see Table I)

TABLE I

TYPE	APPLIED DIFFERENTIAL PRESSURE	OUTPUT PRESSURE	
BK□□□□1	Minimum	3 psig	3 psig
	Maximum	27 psig	15 psig
BK□□□□2	Minimum	27 psig	15 psig
	Maximum	3 psig	3 psig

26 Apply maximum differential pressure. Output should be desired value (see Table I).

NOTE: Minor range change may occur when suppression spring is added to Transmitter. Range screw may have to be turned slightly to obtain desired output value with maximum differential applied to measuring diaphragm

27. Check calibration of Transmitter by applying differentials equivalent to 0, 20, 40, 60, 80 and 100%. If Transmitter output was linear when checked without suppression but is now non-linear:

a. Apply minimum differential; output should be as indicated in Table I.

b. Change output pressure about 1 psi, using zero spring adjustment.

c. Recorrect output pressure to desired output value with suppression spring adjustment.

d. Check linearity. Repeat steps as necessary

NOTE: If Transmitter has worked satisfactorily without suppression spring but now has a non linear output or hysteresis, the probable causes are: (1) adding suppression spring has caused available clearance within capsule to change (procedure outlined above will correct), or (2) dowel pins are bearing in slots of suppression spring guide bar (suppression spring is not aligned properly or slots must be enlarged.)

28. If calibration is satisfactory, place Transmitter in service. If calibration still cannot be achieved, check Booster Relay as outlined under 'Calibrating the Booster Relay' on page 27.

Calibration Procedure Type BK8 and BK9

When Transmitter is in use, pressure in chamber beneath sealing diaphragm varies between atmospheric and maximum service pressure in tank or drum, resulting in slight upward movement of sealing diaphragm, force beam, and attachments. In order that error is not introduced, this movement must be parallel to plane of vane. Type BK8 and BK9 units are aligned at the factory. (Type BK7 units do not require alignment.)

NOTE: Factory alignment is for 750 psig (mid range) operating pressure unless unit is ordered calibrated to a specific operating pressure (For special units, see Calibration Data Sheet.)

Static realignment is required if mid range operating pressure is other than 750 psig or after any of following operations:

- a. Readjustment of vane adjustment screw;
- b. Readjustment of nozzle in its bracket;
- c. Movement of base of tension strip assembly (Item 42, Figure 2a);
- d. Loosening of socket head screws (11) and (13) holding mechanism frame to base housing (Figure 25);
- e. Changing range adjustment any appreciable amount; or
- f. Complete disassembly of Transmitter

NOTE: To check "Static Alignment" use the following procedure. Transmitter should be as received from factory. If continuing 'Pre-Service Adjustments', omit references to suppression spring.

1. Check that pipe plug is tightened securely into measuring diaphragm assembly below the force beam

2. With atmospheric pressure on both sides of capsule, obtain an output pressure from the Transmitter within the range span of the instrument. For low suppression, no adjustment need be made. However with high suppression, the suppression spring adjustment (Figure 17) should be turned to obtain some output pressure.

3. Apply HYDRAULICALLY the maximum service pressure to both sides of measuring diaphragm using teed connections.

WARNING: This pressure must be applied hydraulically due to danger of explosion when using highly compressed gases.

4. Note whether there has been a change in Transmitter output pressure. If the amount of change, within the range of static pressure for which accuracy is required (see Example below), is beyond required tolerances, continue with the following procedure. If the amount of change is negligible, repeat 'Pre Service Adjustments'.

EXAMPLE: Output change between atmospheric and maximum operating service pressure of 1000 psig might be 0.5 psi. Static alignment would be desired if it is necessary that the Transmitter transmit accurately over a wide range of static pressure. If, however, accuracy is only required for static pressures between 900-1100 psig, and output change in this range was only 0.1 psi, static alignment might be considered unnecessary, and the instrument merely zero adjusted to a 3.0 psig output when put into service and under service pressure.

5. If static alignment is satisfactory and if the suppression spring adjustment has been turned prior to starting this test, the required initial suppression differential should be applied and the suppression spring readjusted to obtain required output pressure. If static alignment is not satisfactory, continue with step 6.

6. Remove service pressure from diaphragm.

7. With both sides of measuring diaphragm open to atmosphere, adjust zero adjustment spring until output pressure is 3.0 psig.

8. With output of Transmitter at 3.0 psig, remove pipe plug in bottom of high pressure side of diaphragm housing. Insert Allen wrench thru pipe plug hole and tighten connector clamp nut *securely* (see Table of Torque Values). Output pressure of Transmitter should remain at 3.0 (± 0.5) psig. If change is greater than 0.5 psig, loosen connector clamp nut and retighten, turning Allen wrench carefully so it does not push force beam from its neutral position. Replace pipe plug in bottom of diaphragm housing.

9. With diaphragm capsule clamped properly, apply an equalized operating service pressure simultaneously to both sides of measuring diaphragm capsule. If output pressure changes less than 0.5 psig, adjust vane adjustment screw to obtain 3.0 psi when elevated static pressure is im pressed on capsule.

a. For decrease in output pressure with increase in static pressure, turn vane screw counterclockwise a small amount.

NOTE: Vane screw is an extremely sensitive adjustment. Make adjustments in small increments.

b. For increase in output pressure with increase in static pressure, turn vane screw clockwise a small amount.

c. Release static pressure and observe output pressure with zero static pressure. Readjust zero adjustment spring to obtain 3.0 psig.

d. Repeat procedure until no change in output is noted when checking at atmospheric and at operating static pressure.

10. If change in output pressure due to application of static pressure is greater than 0.5 psi, or output drops to zero, or output remains above minimum range value with zero spring adjustment at minimum setting, readjust tension strip feet (Item 42, Figure 25) as outlined below:

a. Remove service pressure from diaphragm. Loosen screws holding tension strip feet to mounting plate. Force feet in proper direction to reduce error in output pressure as follows:

(1) For decrease in output pressure, move tension feet toward restoring bellows.

(2) For increase in output pressure, move tension feet away from restoring bellows.

NOTE: When screws on tension strip feet are loosened, output pressure may change; this change will be recovered when screws are tightened. Movement of tension feet will cause another change in output pressure which will not be recovered, and amount of this change is an indication of amount that tension strip feet were moved (thus an aid in static alignment procedure).

b. Tighten tension strip mounting screws to 40 in lb.

11. Apply service pressure to diaphragm. If output pressure changes by less than 0.5 psig, adjust output pressure to 3.0 psig with vane adjustment screw. If error is too large to correct with this adjustment, repeat step 10. If output still changes by an amount greater than 0.5 psig, diaphragm capsule must be repositioned. Refer to "Replacing Diaphragm Capsule."

12. If vane adjustment screw has been turned more than 1/4 turn or if tension strip feet have been moved to achieve static alignment, connector clamp nut should be unclamped and re clamped for best perform

ance. After reclamping, static alignment should be rechecked. Once static alignment has been achieved, vane, vane adjustment screw, nozzle, and tension strip feet should not be touched.

13. Diaphragm capsule is now clamped to force balance mechanism. With zero differential on measuring diaphragm, Transmitter output should read 3.00 psi. Apply maximum differential (disregard initial suppression) to high pressure side of diaphragm capsule. Transmitter output should read 15 psig (± 0.6 psig) for Type BK□□□□ unit and 27 psig (± 1.2 psig) for Type BK□□□□ unit. If not, turn range adjustment screw (down to increase maximum output) to reposition fulcrum for desired output value.

14. Remove differential and rezero unit, if required, to obtain 3.00 psi. Apply maximum differential and check maximum output value.

15. Repeat steps (13) and (14) until minimum and maximum output values are obtained.

16. Check differential values at 20, 40, 60 and 90% to insure Transmitter output pressure is linear.

17. Turn OFF air supply to Booster Relay

18. Remove five screws holding spring and bellows support to mechanism frame and bellows.

19. Add suppression spring. Lock nut on threaded spring should be tightened to fix one end of spring to spring support assembly. Slots in guide bar on suppression spring should be parallel to base plate.

20. Add spring adjustment nut (Item 14 or 19, Figure 25) and replace spring and bellows support plate. Insure that pins are not misaligned with slots in guide bar on suppression spring.

21. Turn ON air supply.

22. Apply minimum differential pressure (including suppression) to appropriate side of measuring diaphragm capsule and adjust suppression spring tension to obtain desired output value (see Table I)

23. Apply maximum differential pressure. Output should be desired value (see Table I)

NOTE: Minor range change may occur when suppression spring is added to Transmitter. Range screw may have to be turned slightly to obtain desired output value with maximum differential applied to measuring diaphragm.

24. Check calibration of Transmitter by applying differentials equivalent to 0, 20, 40, 60, 80, and 100%. If Transmitter output was linear when checked without suppression but is now non linear:

Apply minimum differential, output should be as indicated in Table I

b. Change output pressure approximately 1.0 psi, using zero spring adjustment

c. Recorrect output pressure to desired value with suppression spring adjustment

d. Check linearity. Repeat steps as necessary.

NOTE: If transmitter works without a suppression spring, but has a non linear output or hysteresis, probable causes are: (1) adding suppression spring caused available clearance within capsule to change (above procedure will correct). (2) dowel pins are bearing in slots of suppression spring guide bar (suppression spring not properly aligned or slots are enlarged)



25. If calibration still cannot be achieved, check Booster Relay as outlined under 'Calibrating the Booster Relay' below. If calibration is satisfactory, place Transmitter in service.

Type BK Transmitter

VALVE ADJUSTMENT SCREW

OUTPUT PRESSURE CONNECTION 1/4 NPT

NOZZLE BACK PRESSURE SPRING ADJUSTMENT SCREW



F L L S T E R H E A D
S T A I N L E S S S T E E L
M A C H I N E S C R E W

FIGURE 18 - Booster Relay Adjustment

Calibrating the Booster Relay

The Booster Relay has two adjustments. The valve adjustment, Figure 18, adjusts the inlet valve seat to balance effective areas of chamber 1 and chamber 4 diaphragms for an even reset rate. This adjustment is sealed with Loctite cement (Grade C) after factory calibration. Do not change this adjustment unless absolutely necessary. If the Relay has been disassembled, or the valve adjustment setting has been changed for any reason, check calibration of the unit as outlined below. The second adjustment determines nozzle back pressure.

1. Remove Relay from Transmitter.

2. Attach calibration block (Figure 19) to Relay using screws removed in step 1. Connect in calibration setup shown in Figure 20. Connect mercury manometer to Booster Relay output pressure connection (marked

'L' on Relay). Connect another mercury manometer to tee fitting in piping to input connection of calibration block. Calibration block, Part No. 5320549-1, may be purchased from Bailey Meter Co.

3. Apply supply pressure of 15 psi (or 3 15 range) or 30 psi (or 3 27 range) to supply connection (marked 'S' on Relay).

4. Apply 2.5 psi to calibration block input connection to simulate nozzle back pressure. Adjust nozzle back pressure screw (Figure 18) to obtain a Booster output between 3 psi and 5 psi. Increase input pressure to calibration block by 0.1 psi.

a. If Booster output pressure does not increase to 15 psi (or 3 15 range) or 27 psi (or 3 27 range), or if output pressure slows down (decelerates) as it increases, turn the valve adjustment screw (Figure 18) clockwise a small amount.





FIGURE 19 - Booster Relay Calibration Block, Part No. 5320549 1



b. If rate of output pressure speeds up (accelerates), turn valve adjustment screw counter clockwise a small amount.

5. Repeat step 4 until output pressure changes at a constant rate. The difference between the nozzle back pressure which causes a constant rise and that which causes a constant drop should be about 0.1psi and should occur between 2.1 psi and 2.3 psi.

6. If Booster Relay cannot be calibrated as described above, fault may be caused by leakage. Refer to 'Troubleshooting' to check Booster Relay for leakage.

7. When correct calibration is obtained, remount Booster on Transmitter

8. Perform steps under "Pre Service Adjustments", page 19.




FIGURE 20 Suggested Calibration

HOW THE TRANSMITTER OPERATES

TYPE BK DIFFERENTIAL PRESSURE TRANSMITTER

The Type BK Transmitter, shown schematically in Figure 21, measures differential pressure and transmits a pneumatic output signal proportional to the applied differential pressure. The measured differential pressure can represent either level or flow

The Transmitter consists essentially of a measuring diaphragm capsule connected to a force balance restoring mechanism with a vane-nozzle position detector. An output pressure (produced by a Booster Relay described on page 29), proportional to the applied differential, is the balancing force of the force balance mechanism

Pressure is applied to both sides of the measuring diaphragm capsule. When the differential pressure applied to the measuring diaphragm is constant, the measuring diaphragm is centered within its housing and the vane nozzle relationship is such that nozzle back pressure remains constant, maintaining the vane and nozzle at their 'at balance' position.

When differential pressure applied to the measuring diaphragm increases, the measuring diaphragm moves away from the Transmitter, pulling the connector rod so that: (1) there is a slight rotation of the force beam, (2) moving the vane closer to the nozzle, (3) increasing nozzle back pressure, (4) causing an increase in Booster Relay output pressure, (5) which is applied to the restoring bellows, (6) fastened between the frame and restoring beam, (7) causing the restoring beam to exert greater force on the force beam, (7) causing rotation of the force beam to its original position

The Booster Relay output pressure will continue to increase until the force beam (vane and nozzle) returns to an 'at balance' condition. The Booster output pressure stabilizes at this new higher pressure with the measuring diaphragm capsule centered in its housing

The force balance mechanism maintains output pressure and restoring pressure at a value that balances the moment of restoring force on the force beam against the moment of force from the measuring diaphragm

Type BK Transmitter




FIGURE 21 - Schematic of Type BK Differential Pressure Transmitter

The adjustable fulcrum is moved vertically on the restoring beam (Figure 21) to determine the range of applied differentials that will produce standard Booster Relay output ranges. This range adjustment setting determines the length of arm y (Figure 21). As y is made shorter, a larger restoring force is required to balance force Dd . In addition, distance x , on the restoring beam, is lengthened so that greater force from the restoring bellows is required to produce force R . Turning the range adjustment down increases Booster Relay output pressure; turning the adjustment up decreases the pressure when constant differential pressure is maintained on the measuring diaphragm.

Suppression Spring

When a suppression spring (Figure 21) is used, it acts to limit effective torque acting on the force beam (torque opposed by the restoring bellows) by setting up a torque on the force beam.

For closed tank measurement with condensing atmosphere, (with normally high and low pressure sides of diaphragm reversed) the suppression spring is in tension and

acts to reverse Booster Relay output with respect to differential. Therefore, output pressure is minimum value at maximum differential.

For open or closed tank measurement with non-condensing atmosphere, the suppression spring nullifies the effect of the head (between Transmitter and minimum tank level) on the Transmitter. Therefore, the spring is in compression, acting in the same direction as the restoring bellows.

BOOSTER RELAY

The Booster Relay is shown schematically in Figure 22. Three diaphragms divide the inside of the unit into four air pressure chambers. The diaphragms move together because they are clamped at their centers by the diaphragm assembly. Since chambers 1 and 4 are connected and are equal in effective diaphragm area, their opposing forces on the diaphragm assembly balance each other. Chamber 2 is open to atmosphere. The operator spring exerts a force downward on the diaphragm assembly. Thus, since chamber 3 pressure exerts a force upward, the position of the diaphragm assembly is a direct function of chamber 3 pressure.




FIGURE 22 Schematic of Booster Relay

Supply air enters chamber 3 and the nozzle thru a pressure reducing orifice. The rate of air flow from the nozzle determines the magnitude of the pressure in chamber 3. At balance this pressure is about 2 psig, which is the pressure required to balance the downward force of the operator spring

When the applied differential pressure increases, rotation of the force beam moves the vane closer to the nozzle tip, retarding the flow of air from the nozzle and increasing the pressure in chamber 3. The pressure increase moves the diaphragm assembly up, opening the inlet valve and closing the exhaust valve. Supply air enters chamber 1 thru the inlet valve, causing the output pressure of the Booster Relay to begin to increase.

Chamber 1 pressure is also applied to the restoring bellows. As the pressure in

chamber 3 increases, the restoring bellows extends, moving the vane away from the nozzle. The resultant increased rate of air flow from the nozzle causes the pressure in chamber 3 to begin to decrease

Chamber 1 pressure will continue to increase until the vane is restored to the balance position with respect to the nozzle which produces a pressure of 2 psig in chamber 3. The operator spring by then has moved the diaphragm assembly down to its original position, closing the inlet valve and causing the Booster Relay output pressure to stabilize at the new, increased value

When the applied differential pressure decreases, the operation of the Booster Relay as described above is reversed and the Booster Relay output pressure stabilizes at a new decreased pressure

SPECIFICATIONS

OPERATING CONDITIONS

INFLUENCE		NOMINAL	REFERENCE (RANGE)	NORMAL	OPERATIVE LIMITS
AMBIENT TEMPERATURE		75F	CALIB TEMP ±2.5F	40F TO 140F	0°F TO 180F
SUPPLY PRESSURE	TYPE BK01□□	18 PSIG	CALIB PRESS ±0.25 PSI	16 TO 20 PSIG	40 PSIG MAX
	TYPE BK02□□	30 PSIG	CALIB PRESS ±0.25 PSI	28 TO 35 PSIG	40 PSIG MAX

AMBIENT TEMPERATURE EFFECT

0.02% SPAN PER DEGREE F DEVIATION FROM CALIBRATING TEMPERATURE IF SPAN IS AT LEAST 20% OF FULL RANGE

AIR SUPPLY PRESSURE EFFECT

AT REFERENCE PRESSURE 0%
PER PSIG DEVIATION FROM REFERENCE PRESSURE ±0.2%

REFERENCE PERFORMANCE CHARACTERISTICS (% RANGE SPAN)

ACCURACY ±0.5%
HYSTERESIS 0.5%
INDEPENDENT LINEARITY ±0.5%
REPEATABILITY 0.25%

DESIGN DATA

AIR CAPACITY (FOR 1 PSI DROP) 0.6 TO 0.9 SCFM

AIR CONSUMPTION (AT BALANCE ON DEAD END SERVICE)
0.1 SCFM (3 TO 15 PSIG)
OR 0.15 SCFM (3 TO 27 PSIG)

CASE CLASSIFICATION

WEATHERPROOF

OVERRANGE PROTECTION

FULL RATED SERVICE PRESSURE (50 PSIG OR 1500 PSIG) TO EITHER SIDE OF DIAPHRAGM

TABLE II - TORQUE VALUE

PART NAME	LOCATION	TORQUE VALUE MAX SERVICE PRESSURE	
		50 psig	1500 psig
Force Beam Nut	Holding Force Beam to Sealing Diaphragm	15 ft-lb	15 ft-lb
Connector Clamp Nut	Holding Diaphragm Connector to Force Beam Nut	75 in lb	75 in-lb
No 10 32 Screws	Internal Fasteners in Force Balance Unit	28 in-lb	28 in lb
No 6 32 Screws	Internal Fasteners in Force Balance Unit	12 in lb	12 in-lb
No. 10 32 Nut	Holding Zero Spring to Restoring Beam	28 in lb	28 in lb
Bellows Screw	Holding Restoring Bellows to Mechanism Frame	28 in lb	28 in-lb
Hinge Screw	Holding Hinge and Restoring Beam to Mechanism Frame	12 in lb	12 in-lb
5/16 18 Stainless Socket Hd. Screw	Holding Diaphragm Assembly to Pressure Housing	125 in lb	Not Applicable
Nut & Bolt	Holding Halves of Diaphragm Assembly Together	10 in lb	50 ft lb
No. 10 32 Socket Hd. Screw	Holding Mounting Plate and Sealing Diaphragm to Pressure Housing or Diaphragm Assembly	40 in lb	40 in lb
3/8-16 Hex Hd. Cap Screw	Holding Two Bolt Flange to Diaphragm Assembly	Not Applicable	20 ft lb
1/4-20 Screw	Holding Mechanism to Frame	55 in lb	55 in-lb
8-32 Fillister Head Screw	Holding Booster Relay to Mounting Plate	18 in lb	18 in-lb
Connector	Attaching Connector Strap to Diaphragm Capsule	Not Applicable	30 in lb

Type BK Transmitter





FIGURE 23 - Transmitter Range Charts



EXPLANATION OF NOMENCLATURE



* DIRECT ACTION INCREASING D P INCREASING SIGNAL PRESSURE
 REVERSE ACTION DECREASING D P INCREASING SIGNAL PRESSURE
 AN X IN ANY NOMENCLATURE POSITION INDICATES THE UNIT IS SPECIAL IN THAT RESPECT AN X AS A SUFFIX INDICATES THE UNIT CONTAINS A SPECIAL FEATURE NOT COVERED BY NOMENCLATURE

REPLACEMENT PARTS

SPARE PARTS KITS

The Spare Parts Kits tabulated in Figures 24 thru 28 should be carried in stock. Specify the Spare Parts Kit part number to order a complete kit

ORDERING INDIVIDUAL PARTS

Figures 24 thru 28 are Parts Drawings of the Type BK Differential Pressure Transmitter and Booster Relay. Normally, these drawings will apply to the instrument furnished. However, there may be individual differences in specific assemblies due to:

a. Design changes made since the printing of this Instruction Section, or


b. Special design of equipment furnished to make it suitable for special application.

Therefore, when ordering individual parts, assure the receipt of correct replacements by specifying on the order:

1. Complete nomenclature, serial number, part number, and code label number of equipment for which parts are desired, and

2. Parts Drawing on which each part is illustrated. (The Parts Drawing Number is given in the Figure caption.)

Type BK Transmitter



ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	SEE PARTS DWG P21-28	TYPE B TRAIN INTERNAL MECH	1	4 20x 2	HEX SOC HD CAP SCR	22	6x2603	NAMEPLATE (T SHOWN)
2	SEE PARTS DWG P21-24	MEAS D APH ASSY TYPE BK	13	6x730	1 COVER MTG PLATE	24	1b 2x2	4 HEX HD CAP SCR 4 REQD FOR B8 CR BK9
3	SEE PARTS DWG P21-30	MEAS D APH ASSY TYPE BK	14	6 3/8 x 8	FIL HD MACH SCR 4 REQD	3	8 16x3	4 HEX HD CAP SCR 4 REQD FOR BK
4	509561	RELAY ASSY INCL DES 5 8 20 92	15	5311428	3 O RING 2 REQD	25	7	SPRING LK WASH 4 REQD FOR B8 CR BK9
5	682290	1 COVER	16	4 40x 1 9	FLAT HD MACH SCR	26	3 8	FCR B8 CR BK9
6	882354	1 RET COVER CR 4 REQD	17	30 8	REG SPRING LK WASH 4 REQD	7	4	FCR B8 CR BK9
8	35441	3 SEALING STRIP	18	8 32x2 1 2	FIL HD MACH SCR 2 REQD	96	3 8	FCR B8 CR BK9
9	1 4 20x 2	HEX SOC HD CAP SCR	19	NO 10	REG SPRING LK WASH 4 REQD	97	682317	U BOLT
10	1 4 8 REG	SPRING LCK WASH 3 REQD	20	1982397	1 ZERO LABEL NOT SHOWN	25	3 8 16	HEX NUT 2 REQD
			21	1951346	1 ZERO ADJ COVER NOT SHOWN			

* ITEMS IN LILDED N SPARE PARTS KIT TABULATED ON PARTS DWG P21-28

FIGURE 24 Parts Drawing P21-27, Type BK Differential Pressure Transmitter




FIGURE 25 Parts Drawing P21 28, Internal Mechanism for

Type BK Transmitter

ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	6 32x5 16	PAN HD SEMS EXT, 8 REQD	18	1 4 REG	SPRING LOCKWASHER BK0001 ONLY	38	2756	PALNUT TENSION NUT
2	682091 1	SPRING PIVOT CLAMP 4 REQD	19	682272 1	COM SPRING, ADJ NUT (BK0001 ONLY)	39	682302 1	SPRING SUPPORT ASSY
3	682092 1	SPRING PIVOT CLAMP 4 REQD	20	682301 1	SPRING AND BELLOW SUPPORT	40	10 32x5 8	HEX SOC HD CAP SCR 5 REQD
4	682595 1	MECHANISM FRAME	21	5316488 1	NYLON INSERT BK0001 ONLY	41	NO 10 REG	SPRING LOCKWASHER, 13 REQD
5	5316488 1	NYLON INSERT 2 REQD	22	6 32x5 16	HEX SOC HDLS CUP PT SET SCR (BK0001 ONLY)	42	682305 1	TENSION STRIP ASSY 2 REQD
6	6 32x5 16	HEX SOC HDLS CUP PT SET SCR	23	6 32x1 2	PAN HD SEMS EXT 4 REQD	43	682291 1	FORCE BEAM
7	682494 1	STOP CLAMP (BK7001 ONLY)	24	10 32x5 8	PAN HD SEMS EXT	44	10 32x1 2	HEX SOC HD CAP SCR 4 REQD
8	6 32x5 16	PAN HD SEMS EXT 2 REQD (BK7001 ONLY)	25	682364 1	MANIFOLD CLAMP	45	682293 1	MOUNTING PLATE
9	6 32	HEX NUT BK7001 ONLY	26a	682594 2	BELLOWS BK01 ONLY	46	682089 2	SEALING DIAPHRAGM
10	6 32x1 2	HEX SOC HDLS OVAL PT SET SCR BK7001 ONLY	26b	682594 1	BELLOWS (BK02 ONLY)	47	682282 1	NOZZLE BRKT ASSY
11	1 4 20x7 8	HEX SOC HD CAP SCR	27	682284 1	ZERO ADJ NUT	48	10 32x3 8	PAN HD SEMS EXT 1 REQD
12	1 4 REG	SPRING LK WASH 3 REQD	28	682066 1	ZERO SPRING ASSY	49	4 40x1 4	PAN HD SEMS EXT 2 REQD
13	1 4 20x1 2	HEX SOC HD CAP SCR 2 REQD	29	10 32	HEX NUT	50	683245 1	NOZZLE AIRLINE
14	682278 1	TENSION SPRING, ADJ NUT BK0002 ONLY	30	682295 1	RESTORING BEAM	51	68834 1	CLAMP BLOCK
15	682279 1	EXTENSION SPRING ASSY (BK0002 ONLY)	31	682289 1	SPRING PIVOT HINGE 4 REQD	52	4 40x1 4	HEX SOC HD CAP SCR 5 REQD
16	682273 1	COMPRESSION SPRING ASSY BK0001 ONLY	32	682052 1	RANGE ADJ SCREW	53	682599 1	VANE SPACER
17	1 4 28	HEX JAM NUT BK0001 ONLY	33	197549-1	E TYPE TRIANG RET RING 2 REQD	54	683249 1	NOZZLE VANE
			34	19734 18	SMALL WASHER	55	682573 1	CLAMP PLATE
			35	956328 1	DISC SHAFT SPRING WASH	56	6 32x1 4	HEX SOC HDLS CONE PT SET SCREW
			36	682281 1	ADJ FULCRUM	57	4 40x1 2	FLAT HD MACH S.C.R
			37	682424 1	VANE ADJ SCREW	58	682311 0*	RANGE SCALE

* □ PER ENG DATA

SPARE PARTS KITS	
KIT NO 256034 1 FOR BK01	
KIT NO 256034 2 FOR BK02	
QTY	ITEM
2	5
2	13*
2	15*
1	26a BK01
1	26b BK02
1	46
1	54

*ITEMS 13 15 ON PARTS DWG P21 27




FIGURE 26 Parts Drawing P21 30,

Type BK Transmitter


ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
	662100	1 DIAPHRAGM ASSY (INCL ITEMS 1 THRU 24)	12	682025	1 NYLONSLEEVE 8 REQD	20	5311428	1 O RING
1	SEE NOTE	CODE LABEL	13	682161	1 SEALING WASHER	21	NO 10	LKWASH 9 REQD
2	681978	1 DIAPHRAGM HOUSING	14	5 16 18	HEX NUT 12 REQD	22	682443	1 GASKET 8 REQD
3	681985	1 DIAPH CLAMP PLATE 2 REQD	15	5 16 18v1	1 4 HEX HD CAP SCR 12 REQD	23	682443	9 GASKET
4	681977	1 DIAPHRAGM HOUSING	16	10 32x1 4	PAN HD PHILLIPS SCR 2 REQD	24	683004	1 DIAPH FORCE BEAM CONNECTOR ASSY
5	7 16 20	HEX JAM NUT	17	195148	1* SST PIPE PLUG 2 REQD	25	195213	2 PIPE PLUG
6	681983	1 SPACER	18a	682596	1 BRASS SURGE DAMPENER (STAMPED 2 1 2 REQD 045 DIA PIN)	26	5311428	44 O RING
7	681981	1 STRAP HANGER 2 REQD	18b	682596	3 BRASS SURGE DAMPENER (STAMPED 1 1 2 REQD (.039 DIA PIN)	27	5311428	45 O RING
8	682170	1 DIAPHRAGM ASSY				28	682292	1 HOUSING
9	5311428	7 O RING				29	682383	1 FORCE BEAM NUT
10	6 32x3	8 PAN HD MACH SCR # REQD	19	7 16 SAE	MED PLAIN LKWASH	30	5 16 18x2	3 4 HEX SOC HD SST CAP SCR 4 REQD
11	6 32	HEX NUT 8 REQD						

NOTE SPECIFY NUMBER ON LABEL WHEN ORDERING PARTS

*ASSEMBLED IN TOP OR BOTTOM OF DIAPHRAGM AS REQUIRED FOR TEST PURPOSES

SPARE PARTS KIT PART NO 256038 1	
ITEM	QTY
20	1
9	1
26	1
27	1
12	8
8	1
29	1

Type BK7 Measuring Diaphragm Assembly.



TYPE	ITEM 12	ITEM 1*
BK801CS	683117 2	683122 1
BK802CS		683220 1
BK801CS		683192 1
BK802CS	683117 1	683220 1
BK801CM		683122 9
BK802CM	683117 3	683220 2
BK801CH		683122 3
BK802CH	683117 4	683290 3
BK901CD		683122 4
BK902CD	683117 1	683220 4

KIT NO 256037 1 FOR BK8	
KIT NO 256037 2 FOR BK9	
QTY	ITEM
2	3
2	4
1	13
1	14a(BK8)
1	14b(BK9)
1	13

ITEM	PART NO	NAME
1	SEE NOTE	CODE LABEL
2	315521 2	HIGH STRENGTH NUT 4 REQD
3	1951201 3	O RING 2 REQD
4	682298 1	DIAPH HSG SEAL 2 REQD
5	682333 1	HIGH STRENGTH BOLT 4 REQD
6	682389 1	VENT VALVE ASSY 2 REQD
7	683303 1	HIGH STRENGTH BOLT 4 REQD
8	195148 1	PIPE PLUG (TYPE BK8) 4 REQD
	682332 1	PIPE PLUG (TYPE BK9) 4 REQD


ITEM	PART NO	NAME
9	682312 2	FRONT HOUSING (TYPE BK8)
	682317 1	FRONT HOUSING (TYPE BK9)
10	682321 2	FLANGE CONN (TYPE BK8) 9 REQD
	682321 1	FLANGE CONN (TYPE BK9) 9 REQD
11	682916 2	BASE HOUSING (TYPE BK8)
	682316 1	BASE HOUSING (TYPE BK9)
12	SEE TABLE	FLEXIBLE CONNECTION ASSY
13	682334 1	DIAPHRAGM SEAL

ITEM	PART NO	NAME
4	682393 3	FORCE BEAM NUT (TYPE BK8)
	682393 4	FORCE BEAM NUT (TYPE BK9)
15	682392 1	D WASHER
16	682395 1	CONN LAMP NUT
17	SEE TABLE	CAPSULE ASSY

NOTE: SPECIFY NUMBER ON PART WHEN ORDERING PARTS

FIGURE 27 Parts Drawing P21 29, Type BK8 and BK9 Measuring Diaphragm Assembly

Type BK Transmitter



ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	5320414A1	FELT PAD 2 REQD	4	5316464A4	ORIFICE ASSY
2	53204 3A1	WIRE MESH 4 REQD	5	5316464A1	ORIFICE ASSY
3	5316478A1	ORIFICE CLEANOUT ASSY 2 REQD	6	5311428A11	O RING 2 REQD
			7	5311428A2	O RING 2 REQD

NOTE THE ABOVE ITEMS IN THE QUANTITIES LISTED ARE AVAILABLE AS SPARE
PARTS KIT PT NO 256073A1 SPECIFY THIS NUMBER TO ORDER A COMPLETE
KIT

FIGURE 28 Parts Drawing P21-9, Booster Relay Part No. 5324957 1

Product Warranty

Bailey Meter Company warrants the products manufactured by it to be free from defects in material and workmanship and will repair or replace, at its option, free of charge, for its factory such part or parts which prove defective within one year from date of shipment. In respect to any products which are not an integral part of a product manufactured by the Company, the warranty given by the manufacturer thereof shall apply.

Shipping Damage

We strongly recommend that you inspect and test your instrument as soon as you receive it. If the instrument is damaged or operates improperly, notify the carrier for inspection of the shipment. The carrier's claim agent will prepare a report of damage, a copy of which should be forwarded to your nearest Bailey District Office (see back cover for location). The District Office will then tell you how to have the instrument repaired or replaced.

Service

The Bailey Meter Company is vitally concerned that your Bailey instrument provides continued, fine performance. This instruction manual is designed to fully describe the correct installation, operation, and maintenance of your instrument under recommended conditions. If the need arises, factory trained Service Engineers are on call for prompt, in plant maintenance. Telephone or wire your nearby Bailey District Office to make arrangements for this service.

Replacement Parts and Supplies

Complete parts drawings and recommended spare parts kit information are included in this instruction manual. When replacement parts or supplies are required for maintenance of your Bailey instrument, contact your nearest Bailey District Office (see back cover for location). Always specify complete data on the instrument nameplate on your inquiry or order for parts. Common parts are available for shipment within 48 hours on a speed order basis.

**BAILEY METER COMPANY
HEADQUARTERS
Wickliffe, Ohio 44092**

U S A SALES OFFICES

California Los Angeles
California San Francisco
Colorado, Denver
Connecticut New Haven
Florida Jacksonville
Georgia Atlanta
Illinois Chicago
Kentucky, Louisville
Louisiana New Orleans
Maine Augusta
Maryland Baltimore
Massachusetts Boston
Michigan, Detroit
Michigan, Kalamazoo
Minnesota St Paul
Missouri Kansas City
Missouri St Louis
North Carolina Charlotte
New Jersey, East Orange
New York Buffalo
New York Syracuse
Ohio Cincinnati
Ohio Cleveland
Pennsylvania, Philadelphia
Pennsylvania Pittsburgh
Texas Dallas
Texas Houston
Virginia Richmond
Washington, Seattle
Wisconsin Milwaukee

**BAILEY METER COMPANY LIMITED
PO BOX 14000 QUEBEC**

Alberta Edmonton
British Columbia, Vancouver
Manitoba Winnipeg
Nova Scotia Halifax
Ontario Ottawa
Ontario Toronto
Quebec Montreal

**BAILEY METER AUSTRALIA PTY LTD
REGENTS PARK NSW 2143**

NSW Sydney
Queensland Brisbane
South Australia, Adelaide
Victoria Melbourne
Western Australia Perth

**BAILEY JAPAN COMPANY, LTD
511-1 BARAKU, NAYAMA CHO, TAGATA GUN
SHIZUOKA KEN, JAPAN**

INTERNATIONAL REPRESENTATIVES

Argentina Buenos Aires
Brazil, Rio de Janeiro
England Croydon
France Paris
India, New Delhi
Italy Milan
Japan, Tokyo
Mexico, Mexico City, DF
Puerto Rico San Juan
Spain Madrid
Taiwan Taipei
Turkey, Ankara
And Other Principal Cities

Bailey

a subsidiary of Babcock & Wilcox U S A