


Product Instruction P91-1



Mini-Line[®] 500 Manual Stations Type AL

Bailey Babcock & Wilcox

INDEX

	Page
INSTALLATION	3
Pre-Service Adjustment Check	3
Mounting Manual Station on Panel	3
Installing Connecting Tubing	3
Cleaning Scale Cover	3
Placing In Service	3
OPERATING FUNCTIONS	4
Set Point Manual Station	4
Basic Manual Station	4
Bias Manual Station	5
Tie Back Manual Station	5
ROUTINE MAINTENANCE	6
CORRECTIVE MAINTENANCE	7
Vertical Gage Unit Adjustment	7
Hand Relay Disassembly	7
Hand Relay Adjustment	8
Bias Relay Disassembly	8
Bias Relay Ball and Nozzle Adjustment	9
Bias Relay Adjustment	9
SCHEMATIC OPERATION	10
Hand Relay	10
Bias Relay	10
REPLACEMENT PARTS	11
Spare Parts Kits	11
Ordering Individual Parts	11
EXPLANATION OF NOMENCLATURE	11

Manual Stations





FIGURE 1 Removing Vertical Gage Unit from Manual Station

PRY OFF SNAP-OUT COVER FOR ACCESS TO ZERO ADJUSTMENT SCREWS

RIGHT POINTER ASSEMBLY LEFT POINTER ASSEMBLY



VIEW A-A

FIGURE 2 - Removing Snapout Cover from Vertical Gage Unit

INSTALLATION

Pre-Service Adjustment Check

IMPORTANT: Before placing H, A Station in service, check adjustment of vertical gage units as outlined below. For convenience, perform this check at a test bench before the H, A Station is installed in the panel.

1 Position H, A Station at angle at which it will be mounted in service. Apply pressure corresponding to 10% scale to H, A Station input connection. If pointer reads correctly, proceed to step 4.

2 If pointer does not read correctly, remove vertical gage unit from H, A Station as outlined in Figure 1.

3 Remove snapout cover (Figure 2) and turn zero adjustment screw until pointer reads correctly. Reinstall cover.

4 Apply pressure to gage unit corresponding to 90% and 50% scale. If pointer readings are correct, proceed to step 5. If readings are in correct, refer to "Vertical Gage Unit Adjustment", page 7.

Mounting Manual Station on Panel

Manual Stations are designed for plug in mounting in a panel mounted enclosure (Figure 3). Install enclosure as follows:

5 Make panel cutout in accordance with Figure 3.

6 Loosen mounting screw on front plate which secures Manual Station to enclosure, and remove Station.

7 Slide enclosure thru cutout from front of panel.

8 Place mounting clips (in bag tied to enclosure) in position on enclosure. Tighten clip screws securely against panel.

9 Slide Manual Station into enclosure and secure with mounting screw in front plate.

Installing Connecting Tubing

10. Connect external tubing to manifold connections on rear of enclosure (Figure 3). Connections ports are 1/4 18 NPT female. Use 1/4 inch O.D. copper, aluminum, or plastic tubing.

Cleaning Scale Cover

11 Remove protective tape from scale cover. Clean cover with toothpaste or "Plastar", plastic cover cleaner and polish (obtainable from Bailey Meter Company in 10 ounce jar - specify Part Number 199274 1).

CAUTION: Do not use a solvent which will scratch cover finish or react with plastic cover.

Placing in Service

The Manual Station may now be placed in service as outlined below.

12 Turn on supply pressure to Manual Station (check external tubing connections for leakage).

13. Adjust hand control knob on front plate for desired output (see Figures 4 thru 7 for typical applications).




FIGURE 3 Manual Station Mounting Dimensions

OPERATING FUNCTIONS

Set Point Manual Station

Refer to Figure 4 Output pressure from the Set Point Manual Station is normally applied to a Controller to establish the control set point. The output pressure is produced by a hand relay (see Figure 11) which is manually adjusted by the knob on the Station front plate. A double pointer vertical gage unit indicates Manual Station output (SET POINT) pressure and input (METER) pressure to the Controller.

Basic Manual Station

Refer to Figure 5 Output pressure from the Basic Manual Station is normally applied to a power unit (control drive, valve, etc.) for remote control. The output pressure is produced by a hand relay (see Figure 11) which is manually adjusted by a knob on the Station front


FIGURE 4 - Typical Application
of Set Point Manual Station

plate. A single pointer vertical gage unit indicates Manual Station output (CONTROL) pressure. A double pointer vertical gage unit indicates Manual Station output (CONTROL) pressure and the POSITION of the power unit.

Bias Manual Station

Refer to Figure 6. Output pressure from the Bias Manual Station is normally applied to a power unit (control drive, valve, etc.) for remote control. The output pressure is produced by a bias relay (see Figure 12) which is manually adjusted by a knob on the Station front plate. A double pointer vertical gage unit indicates in put (LOADING) pressure from a Controller and Manual Station output (BIAS) pressure.

Tie-Back Manual Station

Refer to Figure 7. Output pressure from the Tie Back Manual Station is normally applied to a Hand/Auto Station to control the output pressure of a Controller. The Manual Station output pressure is produced by a hand relay (see Figure 11) which is manually adjusted by the knob on the Station front plate. A double pointer vertical gage unit indicates Manual Station output (TIE BACK) pressure and Controller (RELAY) output pressure.




FIGURE 5 Typical Application of Basic Manual Station




FIGURE 6 - Typical Application of Bias Manual Station




FIGURE 7 Typical Application of Tie-Back Manual Station

ROUTINE MAINTENANCE

1 Maintain a clean air supply, free of oil or moisture

2 Check filter in supply inlet port at manifold shortly after installation. If filter (Items 2B and 2C, Figure 13) must be replaced, remove wire mesh disc, felt pad, and second wire mesh disc. Install new filter, making certain wire mesh disc is inserted in inlet port before inserting felt pad.

3 Periodically depress orifice clean out plunger (Figure 8) on rear of hand or bias relay to insure that the orifice remains open and clean. **CAUTION** This operation should only be performed when relay is being bench tested since depressing the plunger while relay is in service may disrupt the process.

4 Whenever necessary, clean plastic scale cover as follows:

a Remove (and replace) scale cover as shown in Figure 9

b Clean cover with a soft cloth which will not scratch the plastic surface. Use tooth paste or "Plastar", plastic cover cleaner and polish (obtainable from Bailey Meter Company, in 10-ounce jar--specify Part No. 199274 1). **Do not use a solvent which will scratch cover finish or react with plastic cover.**





FIGURE 8 Rear View of Manual Station

TO REMOVE SCALE COVER



TO INSTALL SCALE COVER




FIGURE 9 Removing and Replacing Vertical Gage Scale Cover

Manual Stations




FIGURE 10 Vertical Gage Unit Adjustments

CORRECTIVE MAINTENANCEVertical Gage Unit Adjustment

If operational faults occur which are traced to the vertical gage units, make the following adjustment checks:

- 1 Remove gage unit from Manual Station as shown in Figure 1. Pry off snapout cover and remove side cover for access to gage unit adjustments (see Figure 2).
- 2 Apply pressure to Bourdon tube and check block assembly for leakage with a soap-suds solution. If a leak is found, replace entire gage unit. The damaged unit may be returned to the factory for repair.
- 3 Check all links to see that they are properly connected and that they move freely with Bourdon tube movement.
- 4 Make certain that indicating pointer does not rub against side or face of scale. If necessary, bend pointer slightly until it clears scale.
- 5 Check pointer adjustment as outlined below.
 - a Apply pressure to gage equivalent to first major scale division above 0% scale. If pointer does not read correctly, turn zero adjustment screw (Figure 10) until desired reading is obtained.
 - b Apply pressure to gage equivalent to first major scale division below 100% scale. If pointer does not read correctly, turn range adjustment screw (Figure 10) until desired reading is obtained.

c Repeat steps 5a and 5b until pointer reads correctly at both scale divisions.

d Apply pressure to gage equivalent to midscale division. If pointer does not read correctly, but does read correctly in steps 5a and 5b above, alter the shape of U-link at free end of Bourdon tube as follows: 1) If midscale pointer reading is low, spread link slightly, or 2) If midscale pointer reading is high, close link slightly.

6 Repeat steps 5a thru 5d until pointer reads correctly over full scale.

7 Apply 2 psig to Bourdon tube (pointer will read slightly below minimum scale mark). Loosen minimum stop screws (Figure 10) and position minimum stop next to Bourdon tube end stop; tighten screws.

8 Apply pressure to Bourdon tube corresponding to maximum scale value plus 0.25 psig (pointer will read slightly above maximum scale mark). Loosen maximum stop screws and position maximum stop next to Bourdon tube end stop; tighten screws.

9 To return gage unit to service, reverse the order of the operations outlined in step 1 above.

Hand Relay Disassembly

To disassemble the Hand Relay (Part No 5321995 □) for cleaning or replacement of parts, proceed as follows:

1. Refer to Figure 13. Disconnect tubing

and remove two screws (21) holding manifold support (19) to support bracket assembly (7)

2 Remove two socket head screws (23) holding manifold to Relay, and slide manifold and support bracket rearward

3 Remove two socket head screws (12) holding Relay to support bracket (7) and remove Relay

4 Refer to Figure 15. Unscrew valve cap (7) and remove valve stem (11), inlet valve seat (13), and valve seat spring (15)

CAUTION Do not disturb setting of relay adjustment screw (Figure 8) at center of valve cap. This setting is factory set and should not be disturbed unless control bellows has been removed or replaced (see "Hand Relay Adjustment")

5 Unscrew orifice clean out assembly (4) and orifice (14)

6 Relieve spring compression by rotating center adjustment gear (27) counterclockwise until it turns easily

7 Remove four nuts (at corners of valve housing face) and screws securing spring housing (23) to valve housing (9) and separate housings

8 Pull control bellows assembly (16) from valve housing (9). Control bellows assembly is held by exhaust valve diaphragm which snaps into place around valve seat.

9 If desired, unscrew loading spring assembly (19) from adjustment shaft (left hand thread)

10 **To reassemble**, reverse above procedure, observing the following precautions:

a When replacing control bellows assembly (16), make certain exhaust valve diaphragm (29) is properly snapped into place around exhaust valve seat

b When replacing orifice clean out assembly (4), make certain that clean out wire is not bent and passes cleanly thru the orifice

c Make certain that all O rings are undamaged and properly installed. Apply lubricant to O rings when reassembling relay

Hand Relay Adjustment

1 Connect output pressure line of Relay, thru a petcock, to a volume chamber equipped with a suitable pressure gage (0-30 psig) for indicating chamber pressure. Volume chamber may be any pressure tight container with volume of about 300 cubic inches

2 Open petcock and adjust Manual Station control knob to obtain 3 psig pressure in volume chamber

3 Close petcock and adjust control knob to obtain 27 psig (for 3-27 range) or 15 psig (for 3-15 range) output pressure from Relay (read output pressure on Manual Station gage)

4 Open petcock and note time rate of pressure increase in volume chamber

5 Close petcock and adjust control knob to obtain 3 psig output pressure from Relay

6 Open petcock and note time rate of pressure decrease in volume chamber

7 If inlet valve seat is properly adjusted, the time rate of pressure increase as noted in step 4 will be equal to the time rate of pressure decrease as noted in step 6. If these rates are not equal (or if the control bellows or nozzle bellows has been replaced) it will be necessary to make the following adjustment:

a If time rate of pressure increase is greater than the rate of pressure decrease, turn adjustment screw (Figure 8) counterclockwise

b If time rate of pressure decrease is greater than the rate of pressure increase, turn adjustment screw clockwise

NOTE: By turning the relay adjustment screw (Figure 8) on the rear of the Manual Station, the inlet valve seat position can be changed with respect to the neutral position of the exhaust valve seat, in effect, controlling the relative openings of the inlet valve and exhaust valve for a given position of the control bellows

Bias Relay Disassembly

To disassemble the Bias Relay (Part No. 5321885-2) for cleaning or replacement of parts, proceed as follows:

1 Refer to Figure 13 Remove Relay from Manual Station as outlined in steps 1, 2, and 3 under "Hand Relay Disassembly"

2 Refer to Figure 14 Unscrew valve cap (7) and remove valve stem (12), inlet valve seat (16), and valve seat spring (17)

CAUTION Do not disturb setting of relay adjustment screw (Figure 8) at center of valve cap This setting is factory set and should not be disturbed unless control bellows or nozzle bellows has been damaged or replaced or the ball and nozzle assembly has been disassembled

3 Unscrew orifice clean-out assembly (5) and orifice (3)

4 Remove four screws (at corners of valve housing face) securing valve housing (13) to bellows housing (30), and separate housings

5 Pull control bellows assembly (6) from valve housing (13) (Control bellows assembly is held by exhaust valve diaphragm which snaps into place around valve seat)

6 Remove four screws securing spring housing (25) and vane nozzle housing (40) to bellows housing (30)

7 Separate housings and remove nozzle bellows

CAUTION Do not disturb ball and nozzle assembly unless absolutely necessary If, however, the assembly is disturbed because of necessary disassembly procedures, perform the steps outlined under "Bias Relay Ball and Nozzle Adjustment" below before proceeding to step 9

8 Remove loading bellows and spring assembly by turning center adjustment gear clockwise until bellows and spring assembly are free of adjustment shaft.

9 To reassemble, reverse above procedure, observing the precautions outlined under "Hand Relay Disassembly", step 10 Also apply O ring lubricant to U cup packing (Item 32, Figure 14) when reassembling relay

Bias Relay Ball and Nozzle Adjustment

1 When making an adjustment on the ball and nozzle assembly, correct setting of the ball with respect to the nozzle is best made by holding the ball against the nozzle with a blunt ended instrument, and alternately tightening

each screw about 1/2 turn Tighten screws securely

a. To check setting, reassemble Relay, omitting spring housing and loading bellows and spring assembly Insert a piece of sealing gasket material between the nozzle housing and the bellows housing over the output pressure passage (passage opening into volume surrounding ball and nozzle) so output pressure will not escape to atmosphere

b. Apply normal supply pressure to supply pressure port and connect a suitable pressure gage (0-30 psig) to output pressure post. With no external force applied to ball, the distance between ball and nozzle is at maximum and the output pressure should be approximately zero Manually, press ball against nozzle opening using a blunt-ended instrument to prevent side thrust The output pressure should increase to within 3 psi of supply pressure An output pressure less than this indicates that the ball is not centered with respect to the nozzle and adjustment must be repeated

Bias Relay Adjustment

NOTE If the following checks and adjustments cannot be made with Manual Station connected in the system, the output pressure line must be closed off or output connection plugged

1. Adjust Manual Station control knob for zero bias (BIAS pressure equals LOADING pressure)

2. Apply pressure exactly equal to the supply pressure to Manual Station input connection This is most easily accomplished by connecting into supply pressure line.

3. Manual Station BIAS pressure should be 3 psi ($\pm 1/4$ psi) less than input pressure (supply pressure) If not, turn relay adjustment screw (Figure 8) to obtain correct BIAS pressure

NOTE By turning the relay adjustment screw (Figure 8) on the rear of the Manual Station, the inlet valve seat position can be changed with respect to the neutral position of the exhaust valve seat, in effect, controlling the relative openings of the inlet valve and exhaust valve for a given position of the control bellows

4. If correct reading cannot be obtained in step 3 above, and if the ball and nozzle assembly was disturbed, check the ball and nozzle assembly adjustment as outlined on page 9 then repeat steps 1, 2, and 3 above.




FIGURE 11 Schematic of Hand Relay




FIGURE 12 Schematic of Bias Relay

SCHEMATIC OPERATION

Hand Relay

Output pressure from the Set Point, Basic, and The Back Manual Stations is produced by a hand relay (Figure 11). Compression of the loading spring is opposed by pressure in the control bellows so that spring compression and output pressure are always proportional when the unit is balanced.

Turning the control knob in the "increase" direction causes compression of the loading spring. The resulting compression closes the exhaust valve and opens the inlet valve, admitting supply air to the control bellows chamber. The control bellows pressure increases until the bellows has expanded sufficiently to restore the inlet exhaust valve mechanism to its original position (inlet valve closed, exhaust valve flapping). Output pressure is then proportional to the increased loading spring compression, and the system is again at balance.

Turning the control knob in the "decrease" direction reverses the operation described above.

Bias Relay

Output pressure from the Bias Manual Station is produced by the bias relay (Figure 12). Bias relay output pressure is controlled by the input pressure and the bias loading spring. Variations in input pressure applied to the inside of the loading bellows are exactly reproduced in the output pressure, while a constant difference (bias) between input pressure and output pressure is maintained by the bias spring. The compression or tension of the bias spring can be adjusted by the control knob to exert a

maximum force on the loading bellows equivalent to ± 12 psi bias for a 3-15 range or ± 24 psi bias for a 3-27 range.

When the bias relay is in equilibrium, output pressure balances both the input pressure and the force exerted by the compression or tension of the bias spring. This output pressure, plus control bellows spring loading, also balances the nozzle pressure. The control bellows spring exerts a force (compression) on the bellows equivalent to a pressure of 3 psi so that at balance, the nozzle pressure is 3 psi greater than the output pressure. This differential insures the proper direction of flow thru the nozzle.

An increase in input pressure or in bias spring compression expands the loading bellows, moving the ball closer to the nozzle. The air flow from the nozzle is retarded, increasing the pressure in the nozzle bellows. As the nozzle bellows expands, the control bellows is compressed, closing the exhaust valve and opening the inlet valve. Supply air flows thru the inlet valve, increasing the output pressure and starting a restoring action at the loading bellows and at the control bellows. As the output pressure increases, the loading bellows is compressed, moving the ball away from the nozzle, and the control bellows expands, moving the inlet-exhaust valve assembly toward its original position. When the control pressure has increased to a value equivalent to the new input pressure plus bias spring loading, the loading bellows and the control bellows will have been restored to their "at balance" position and the relay is again in equilibrium.

A decrease in input pressure or in bias spring compression reverses the operation of the relay.

REPLACEMENT PARTS

Spare Parts Kits

The Spare Parts Kits shown in Figures 13 thru 16 should be carried in stock. Specify the Spare Parts Kit part number to order a complete kit.

Ordering Individual Parts

Figures 13 thru 16 are Parts Drawings of the Manual Stations. Normally these drawings apply to the unit furnished. However, there may be individual differences in specific units because of:

a. design changes made since the printing of this Instruction Section, or

b. special design of the Manual Stations to make them suitable for a special application

Therefore, when ordering parts, assure the receipt of correct replacements by specifying the Manual Station Module Part Number.


EXPLANATION OF NOMENCLATURE

MANUAL STATION MODULE PART NO.	MANUAL STATION NOMENCLATURE*	RANGE (PSIG)	SCALE LEGEND	
			LEFT INDICATOR	RIGHT INDICATOR
5323260-1	AL02A10	3-27	METER	SET POINT
5323260 2	AL02A50	3-27	DIRECT READING**	SET POINT
5323260-3	AL01A10	3 15	METER	SET POINT
5323260 4	AL01A50	3-15	DIRECT READING**	SET POINT
5323260 5	AL02D10	3 27	RELAY	RESET
5323260-6	AL01D10	3 15	RELAY	RESET
5323270-1	AL02B10	3 27	CONTROL	-
5323270-2	AL02B20	3-27	CONTROL	POSITION
5323270-3	AL01B10	3-15	CONTROL	-
5323270 4	AL01B20	3-15	CONTROL	POSITION
5323280 1	AL02C10	3-27	LOADING	BIAS
5323280-2	AL01C10	3 15	LOADING	BIAS

*NOMENCLATURE appears only on the Manual Station Specification Sheet included in Instruction Books furnished on system or contract jobs. A "5" in the third position of the Nomenclature indicates that the Manual Station module is complete with enclosure, Part No. 5322670-1. An "X" in any Nomenclature position indicates that the instrument is special.

**SCALE LEGEND engraved in terms of variable, such as FLOW, LEVEL, PRESSURE.

20 2F 74 5 6 LC 2 22 24 35




ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	140141	DESCRIPTION FLATE	1	6667	HEX SCREW COVER PT 35	25	SEE TABLE 5	REW 2 REQD
2	532267	ENCLCS RE CLOSED	10	2141	GEAR	34	0 28E	WASHER 2 REQD
2A	531991	CO 4MA HIF ZEE	1	#11 0 00	HEX EPOF LK WASH 4REQD	35	532395	1 SPE ALUMINUMS REW
3B	532004	4 FLLT PAD 2 REQD	2	J26	NO NUT HD SCREW 4 REQD	4	521428	3 CR WASHER SEE TABLE
4	532043	3 WRE MENH DSC 4 REQD	13	SEE TABLE	P PINO ASSEMBLY	2	SEE TABLE	VERT CAL AGE 25
5D	10 375	PAN HD SEMS ENT 4 REQD	14	SEE TABLE	RELAY ASSEMBLY	6	4004	8 HEX 5 C HD COP PT SS
6E	521414	MOUNT CLIP 2 REQD	17	19418	ELBOW CONNECTION SEE TABLE	79	521414	1 FRONT PLATE ASSEMBLY
7F	146255	3 WRE MENH DSC 4 REQD	16	521273	1 LOWER TUB ASSY SEE TABLE	30	3241	9 PAN HD SEMS ENT 4 REQD
8	532299	1 CONTROL PLATE	15	532298	SPACER MANIFOLD SEE TABLE	31	531451	21 SCALE ASSEMBLY SEE TABLE
9	532340	1 FRONT PLATE	18	13283	8 PAN HD SEMS ENT 5 REQD	32	522497	1 CONE TOR SUPPORT
10	11853	4 ROLL PIN	19	512243	1 SLICE BRACKET	33	3214	4 PAN HD SEMS ENT 2 REQD
11	512375	1 DRIVE SHAFT	21	146255	NAMEPLATE	34	3243	16 SEMS ENT 2 REQD
12	532263	SUPPORT BRKT ASSEMBLY	21	10 375	4 PAN HD SEMS ENT 4 REQD			
13	19123	1 RETAILER RING	22	53 170	WAGE SUPPORT			

*FOR DETAILS OF HAND RELAY ASSY 532 95% 1 SEE PTD DW. P91 1 FOR DETAILS OF LBAS RELAY ASSY 5321895 **SEE PTD DW. P91 8
**FOR DETAILS OF VERICAL AGE ASSEMBLY SEE PARTS DRAWING P12 5

TABLE											SPARE PARTS KIT			
PART NO	PSIG	ITEM 13	ITEM 4	ITEM 15	ITEM 16	ITEM 17	ITEM 23	ITEM 24	ITEM 25	ITEM 26	ITEM 31	PART NUMBER 700 34	QTY	ITEM N
532370	1	5323649	5321485	2 REQD	1 REQD	OMIT	10 3243	8	5 REQD	531494	25	MIT		
532370	2	332649	332185	2	2 REQD	1 REQD	0 3243	8	5 REQD	531814	25	MIT		
532370	3	5323254	531945	1	OMIT	5MT	1 REQD	10 3242	14	5 REQD	531508	10	5MT	
532370	4	5323275	531905	1	OMIT	OMIT	1 REQD	10 3242	14	6 REQD	53 4445	2	5MT	
532370	5	5323254	531945	1	OMIT	OMIT	1 REQD	1 3242	14	6 REQD	531195	9	CMIT	
532370	6	5323255	5321045	1	OMIT	5MT	1 REQD	10 3752	14	6 REQD	531424	24	CMIT	
532370	7	5323255	5321045	1	OMIT	OMIT	1 REQD	1 3242	14	7 REQD	53 4445	23	CMIT	
532370	8	5323255	5321045	1	OMIT	OMIT	1 REQD	1 3242	14	6 REQD	531814	20	CMIT	
532370	9	5323255	5321045	1	OMIT	OMIT	1 REQD	10 3752	14	6 REQD	531814	18	1 REQD	
532370	10	5323255	5321045	1	CMIT	CMIT	1 REQD	10 3242	14	6 REQD	53 4445	21	CMIT	
532370	11	5323255	5321045	1	CMIT	OMIT	1 REQD	10 3242	14	6 REQD	531814	18	CMIT	

MANUAL STATION MOD LE PART NUMBER

FIGURE 13 Parts Drawing P91 1, Manual Station Assembly



POSITION OF ITEM 3
FOR PART NO 5321885 2

SECTION B B
(ENLARGED)


ITEM	PART NO	NAME
1	CODE LABEL	SPECIFY NO ON LABEL WHEN ORDERING PARTS
2	NO 10	PL PATT MED LK WASH 8 REQD
3	5316464 1	ORIFICE ASSY
4	5311428 11	O RING
5	5316478 1	ORIFICE CLEANOUT
6	5316974 1	BELLOWS ASSY
7	5316809 1	VALVE CAP
8	5311428 7	O RING
9	5316808 1	VALVE ADJ SCREW
10	10 32x1 3/4	FIL HD SCREW 4 REQD
11	5311428 20	O RING
12	5316811 1	VALVE STEM
13	5321893 1	VALVE HOUSING
14	5317009 1	VOLUME FILLER
15	5311428 23	O RING
16	5316977 1	VALVE SEAT ASSY
17	5316844 1	VALVE SEAT SPRING
18	5311428 24	O RING 4 REQD
19	5316813 1	DIAPHRAGM CLAMP
20	5316812 1	EXHAUST VALVE DIAPHRAGM
21	5320156 1	BELLOWS SPRING

ITEM	PART NO	NAME
22	5317003 1	BALL & VANE ASSY
23	5316975 1	STOP PLATE
24	5316994 1	BELLOWS ASSY
25	5323245 1	SPRING HOUSING
26	10 32x1 3/8	FIL HD SCREW 4 REQD
27	5316793 2	ADJUSTMENT GEAR
28	5316815 1	ADJUSTMENT SHAFT
29	661617 1	CONE PT SET SCREW
30	5323248 1	BELLOWS HOUSING ASSY
31	5316998 1	ADJUSTMENT GEAR
32	5317004 1	U CUP PACKING
33	198173 3	RETAINING RING
34	5316816 1	GUIDE & SPRING SUPPORT
35	5316904 1	COMPRESSION SPRING
36	5316901 1	CLAMP PLATE
37	6 32x3,16	RD HD SCREW 2 REQD
38	NO 1106	SHK LK WASH 2 REQD
39	5316994 1	NOZZLE
40	5323247 1	VANE & NOZZLE HSG ASSY
41	5311428 2	O RING 5 REQD
42	5316838 1	BELLOWS ASSY

NOTE FOR PT NO 5321885 2, ROTATE ITEM (31) 180° TO POSITION SHOWN BY DASHED LINES

SPARE PARTS KIT NO 256128 1	
INCLUDES ITEMS	4, 6, 8, 11, 15, 17, 18, 20, 22, 24, 32, 33, 35, 41, 42

FIGURE 14 - Parts Drawing P91-8, Bias Relay Assembly Part No 5321885 2




ITEM	PART NO	NAME
1	CODE LABEL	SPECIFY NO ON LABEL WHEN ORDERING PARTS
2	5311428 2	O RING GASKET
3	5311428 11	O RING GASKET
4	5316478 1	ORIFICE CLEANOUT
5	10 32x2 1 4	FIL HD SCREW 4 REQD
6	5311428 7	O RING GASKET
7	5316809 1	VALVE CAP
8	5316808 1	VALVE ADJ SCREW
9	5321892 1	VALVE HOUSING
10	5311428 20	O RING GASKET
11	5316811 1	VALVE STEM
12	5311428 23	O RING GASKET
13	5316977 1	VALVE SEAT ASSY
14	5316464 1	ORIFICE ASSEMBLY
15	5316844 1	VALVE SEAT SPRING

ITEM	PART NO	NAME
16	5316802 1	CONTROL BELLOWS ASSY
17	5311428 24	O RING GASKET
18	5316817 1	SPRING SUPPORT
19	5316819 1	LOADING SPRING
20	5316816 1	GUIDE & SPRING SUPPORT
21	198173 3	RETAINING RING
22	5316814 1	ADJUSTMENT SCREW
23	5323245 2	SPRING HOUSING
24	5316998 1	ADJUSTMENT GEAR
25	NO 10	PL PATT MED LK WASH 4 REQD
26	5316815 1	ADJUSTMENT SHAFT
27	5316793 2	ADJUSTMENT GEAR
28	661617 1	CONE PT SET SCR
29	5316012 1	EXHAUST VALVE DIAPHRAGM
30	5316813 1	DIAPHRAGM CLAMP
31	10 32	MED HEX NUT 4 REQD

SPARE PARTS KIT NO 256127 1

INCLUDES ITEMS 2 4 6 10,12 15 17,19,21 29

FIGURE 15 Parts Drawing P91 7, Hand Relay Assembly Part No 5321995 1



ITEM	PART NO	NAME
1	CODE LABEL	SPECIFY NO WHEN ORDERING PARTS
2	SEE TABLE	MINIMUM STOP
3	SEE TABLE	MAXIMUM STOP
5	SEE NOTE	MECHANISM ASSY. INCLUDES ITEMS 5A & 5B
5A	SEE NOTE	BOURDON TUBE & BLOCK ASSY
5B	SEE NOTE	POINTER, SEE TABLE
6	SEE NOTE	SCALE ASSY
7	#3 48x5, 16	PAN HD STL SCR 4 REQD
8	NO 1203	SHK LK WASH 4 REQD
9	5316456 1	WASHER 2 REQD
10	5314337 1	FASTENER, 2 REQD
11	5314336 1	COVER PLATF ASSY
12	6 32x7/8	PAN HD EXT SEMS 3 REQD
13	SEE NOTE	COVER
14	6 32x1/4	PAN HD EXT SEMS 4 REQD
15	5314294 1	SCALE WINDOW
16	SEE TABLE	GASKET
17	5322355 1	GASKET
18	SEE NOTE	CASE ASSY

SPARE PARTS KIT NO 256028 1	
QUANTITY	ITEM NO
2	15

	POINTER	GAGE UNIT RANGE	ITEM 2	ITEM 3	ITEM 16
	DOUBLE	3 27	5315411 1	5315411 2	5322195 2
	SINGLE	3 27	5315411 1	5315411 2	5322195 1
	SINGLE	3 15	5315701 1	5315411 1	5322195 1
	DOUBLE	3 15	5215701 1	5315411 1	5322195 2

NOTE SPECIFY TYPE, MODEL, SERIAL NUMBER, AND RANGE OF INSTRUMENT
ALSO FOR POINTER (ITEM 5B) SPECIFY WHETHER LEFT RIGHT OR BOTH LEFT AND RIGHT ARE DESIRED
ALSO FOR SCALE (ITEM 6) SPECIFY LEGEND AND RANGE FIGURES

FIGURE 13 Parts Drawing P12-5, Vertical Gage Unit Assembly

**BA LEY METER COMPANY
HEADQUARTERS**

29801 Euclid Avenue
Wickliffe, Ohio 44092

U S A D I S T R I C T O F F I C E S

California Los Angeles
California San Francisco
Colorado Denver
Connecticut New Haven
Florida Jacksonville
Georgia Atlanta
Illinois Chicago
Kentucky Louisville
Louisiana New Orleans
Maine Augusta
Maryland Baltimore
Massachusetts Boston
Michigan Detroit
Minnesota Minneapolis
Missouri Kansas City
Missouri St. Louis
North Carolina Charlotte
New Jersey East Orange
New York Buffalo
New York Syracuse
Ohio Cincinnati
Ohio Cleveland
Pennsylvania Philadelphia
Pennsylvania Pittsburgh
Texas Dallas
Texas Houston
Virginia Richmond
Washington Seattle
Wisconsin Milwaukee

**BA LEY METER COMPANY LIMITED
POINTE CLAIRE 730 QUEBEC**

Alberta Edmonton
British Columbia Vancouver
Manitoba Winnipeg
Nova Scotia Halifax
Ontario Ottawa
Ontario Toronto
Quebec Montreal

**BA LEY METER AUSTRALIA PTY LTD
REGENTS PARK NSW 2143**

NSW Sydney
Queensland Brisbane
South Australia Adelaide
Victoria Melbourne
Western Australia Perth

INTERNATIONAL REPRESENTATIVES

Argentina Buenos Aires
Brazil Rio de Janeiro
Chile Santiago
England Croydon
France Paris
India New Delhi
Italy Milan
Japan Tokyo
Mexico Mexico City DF
Puerto Rico San Juan
Spain Madrid
Taiwan Taipei
Turkey Ankara
And Other Principal Cities

Bailey

a subsidiary of Babcock & Wilcox U.S.A.

Form P91 1971
GM Limited U.S.A.
August 1971