


Bailey Control Systems**Product Instruction
P92-12****MINI-LINE 520***
Function Generator
Type FG

Instruction Book Price \$6.00

Form P92 12A L th n U S A 578

*Reg. U.S. Pat. Office

©Bailey Meter Company 1978

Babcock & Wilcox
Bailey Meter Company, U.S.A.

WARNING	ATTENTION
<u>INSTRUCT ON MANUALS</u>	<u>MANUELS D OPERAT ON</u>
DO NOT NSTALL MA NTA N OR OPERATE TH S EQUI PMENT W THOUT READ NG, UNDERSTAND NG AND FOLLOW NG PROPER Babcock & Wilcox Ba ey Meter Co USA NSTRU CT ONS AND MANUALS OTHER SE NJURY OR DAMAGE MAY RESULT	NE PAS METTRE EN PLACE RÉPARER OU FA RE FONCT ONNER CE MATÉ R EL SANS AVO R LU, COM PR S ET SU V LES NSTRU CT ONS RÉGLEMENTA RES DE Babcock & W. cox Ba ey Meter Company USA TOUTE NÉGL GENCE À CET ÉGARD POURRA T ÊTRE UNE CAUSE D ACC DENT OU DE DÍ FA LLANCE DU MA TÉ R EL

INDEX

	<u>Page</u>
INSTALLATION	2
PLACING IN SERVICE	5
ROUTINE MAINTENANCE	6
COMPLETE CALIBRATION	8
TROUBLESHOOTING	13
OPERATION	16
NOMENCLATURE	18
SPECIFICATIONS	18
REPLACEMENT PARTS	19

INSTALLATION

WARNING THIS UNIT SHOULD NOT BE INSTALLED IN AN ENVIRONMENT CONTAINING CHLORINATED OR AROMATIC HYDROCARBONS THESE ELEMENTS WILL DAMAGE THE POLYCARBONATE COVER THE COVER WILL ALSO BE DAMAGED BY AMINOS, ALKALIES AND AMMONIA

AVERTISSEMENT CET ENSEMBLE NE DOIT PAS ETRE INSTALLE DANS UN ENVIRONNEMENT CONTENANT DES HYDROCARBURES AROMATIQUES OU CHLORES CES ELEMENTS ENDOMMAGERAIENT LE COUVERCLE EN POLYCARBONATE L'AMMONIAQUE, L'ALCALI ET LES AMINES ENDOMMAGENT EGALEMENT LE COUVERCLE

vapors and extremes in temperature and humidity
Storage temperatures should fall within limits of 20°F and +160°F (29°C and +72°C)

Mounting and External Connections

The Function Generator is designed for wall or surface mounting and should be mounted as follows

1 Attach unit to wall, panel or relay rack as shown in Figure 1 and secure with three 1/4 inch cap screws, nuts and lock washers

NOTE Unit must be mounted as indicated in order to function properly

2 Make necessary adjustments for particular service as outlined under "Placing In Service", "Adjusting for Service (Nulling Procedure)"

3 Make external connections to mounting base (Figures 1 and 2) Connections are 1/8" 27 NPT female

4 Adjust air supply to mounting base to 18 to 20 psig (124 to 138 kPa) See "Quality Stand ard for Instrument Air", 1975, ISA S7.3 at the end of this section

Unpacking and Storage

1 Check for any obvious damage to shipping carton or contents Report any damage to carrier

2 Make certain that unit is correct range for intended service (refer to identification label)

3 If unit is to be stored repack in original container and store in an area free of corrosive

NOTE If tubing elbows are desired, the following fittings are recommended

E2, E4 and output - 1/8 NPT male to tubing elbow

E1, E3, E3R and S 1/8 NPT x 1" nipples and 1/8 NPT female to tubing elbows

To facilitate assembly, install the E2 and output tubing bellows first

Quality Standard for Instrument Air, 1975, ISA-S7.3

4.1.1 Outdoor installations (where any part of the instrument air system is exposed to the outdoor atmosphere)

The dew point at line pressure shall be at least 10°C (18°F) below the minimum local recorded ambient temperature at the plant site

4.1.2 Indoor installations (Where the entire instrument air system is installed indoors)

The dew point at line pressure shall be at least 10°C (18°F) below the minimum temperature to which any part of the instrument air system is exposed at any season of the year. In no case should the dew point at line pressure exceed 2°C (approximate 36°F)

4.2 Particulate

The maximum particulate concentration in the air stream at the instrument shall be three (3) micrometers

4.3 Oil Content

The maximum total oil or hydrocarbon content exclusive of non condensables shall be as close to zero (0) w/w or v/v as possible and under no circumstances shall it exceed one (1) ppm w/w or v/v under normal operating conditions

4.4 Contaminants

The instrument air shall be free of all corrosive contaminants and hazardous gases, fumes, or toxic which may be drawn into the instrument air stream. If contaminants exist in the compressor intake area the air should be taken from an elevated or remote location free from contamination or processed to remove such contamination. Any cross connections or process connections to the instrument air piping shall be so stated to preclude contamination of the air system. A regular periodic check should be made to assure high quality instrument air




FIGURE 1 External and Mounting Dimensions, Type FG Function Generator.




FIGURE 2 Tubing Connections and Switch Settings for Type FG Function Generator

PLACING IN SERVICE

Function Generators which have been specially calibrated at the factory for a particular service (low rise cam, gain 8 to 12), can be placed directly in operation

IMPORTANT If this factory calibration has been changed (e.g., thru bellows rotation) the unit must be recalibrated as outlined under "Complete Calibration"

If integral control action is required a volume chamber and bleed valve must be placed in series between the booster relay and the "C" bellows. Derivative action may be provided by placing a volume chamber and bleed valve in the input signal line (Figure 8)

In any case, calibration should be verified by applying several input pressures for which the desired output pressures are known. If incorrect output pressures result the unit must be recalibrated

Repeat the application of input pressures with known outputs. If output pressures are now correct the unit may be placed in service. If output pressures remain incorrect, the calibration has shifted and must be reset

Adjusting For Service (Nulling Procedure)

1 Disconnect spring (Parts Drawing P92 12 1, Item 19) from end of connecting rod (Item 16) and remove rod from cylinder. Rotate rod 180° clockwise to allow for free gain arm movement

2 Loosen two hex head cap screws (Item 47) and move nozzle support (Item 5) all the way to the left

3 Place function switch in "P" position, direct/reverse switch in "D" position and by pass switch in position "1"

4 Apply 18 to 20 psig (124 to 138 kPa) supply to "S" connection

5 Apply 3 0 + 01 psig (62 + 07 kPa) input to "E1" connection, inputs to E2, E3, E4 at 0 0 psig

6 Move gain arm to position 10 on gain scale decal and adjust A/B bias screw until output equals 3 0 + 01 psig (20 6 + 07 kPa)

7 Move gain arm to position 1 on gain scale decal and adjust C/D bias screw until output equals 3 0 + 01 psig

8 Repeat step 5 and 6 until difference between output at gain setting 10 and output at gain setting 1 is less than 0 2 psig (1 4 kPa)

9a Move gain from 1 to 10 and note any change in output between these settings. At point of greatest deviation, adjust error three times the error, in direction of error, using null adjustment screw on gain arm

b Set gain to 1 and readjust C/D bias screw to required pressure

c Set gain to 10 and readjust A/B bias screw to required pressure

10 Repeat steps 7 thru 9c until gain arm can be moved from gain setting of 1 to 10 with output remaining constant at 3 0 + 12 psig (20 6 + 83 kPa) + 1 0% of span

11 When output signal remains at 3 0 ± 12 for gain settings from 1 to 10, nulling procedure is complete

12 Remove supply pressure to "S" connection

13 Reconnect spring (19) to end of connecting rod (16)

ROUTINE MAINTENANCE

1 Air supply to Controller must be kept free of dirt, oil and moisture for satisfactory operation. Inspect felt filters in mounting base and replace them if they are dirty. Frequency of filter replacement will depend on the quality of supply air. See "Quality Standard for Instrument Air", ISA S7.3, 1975 under "Installation".

NOTE These filters are included as added protection only and are not intended to take place of required clean air supply.

2 When necessary, replace felt pad air filters in E1, E2, E3R and S connections (Figure 4) as follows:

- a Turn off supply air and disconnect supply air and output lines noted in (2) above.
- b Remove fittings.
- c Remove wire mesh discs and felt pads with pick or similar instrument.
- d Replace felt pads and wire mesh discs.
- e Replace fittings.

f Reconnect supply air and output lines to mounting base.

3 All pressure connections must be kept air tight. Check all air pressure connections for leakage with suitable leak detector solution.

4 Inspect nozzle tip (Figure 8) and vane for deposits of oil, dirt, etc. Clean with a suitable solvent.

5 Clean booster using orifice cleanout plunger, WHEN EQUIPMENT IS NOT OPERATING.

WARNING USE OF THE BOOSTER CLEANOUT DEVICES WHEN EQUIPMENT IS OPERATING ON LINE CAUSES PNEUMATIC SIGNAL "BUMP" WHICH COULD CAUSE SERIOUS SYSTEM UPSET.

AVERTISSEMENT L'EMPLOI DU DISPOSITIF DE NETTOYAGE DU SURPRESSEUR PENDANT QUE L'EQUIPEMENT EST EN FONCTIONNEMENT DIRECT PROVOQUE UN "CONGEMENT" DU SIGNAL PNEUMATIQUE ET RISQUE DE CAUSER UN DEREGLEMENT SERIEUX DU SYSTEME.





FIGURE 3 Function Generator Adjustments

Mini Line 520 Function Generator, Type FG

- a To clean booster orifice push cleanout plunger (Figure 3)
- b Check output bleed orifice located just

below orifice cleanout plunger for normal small air bleed

c If necessary, clean out any obstructions by manipulating cleanout wire



A6995

FIGURE 4 External Connection Ports

COMPLETE CALIBRATION

If the unit has been disassembled for any reason, or factory calibration has been disturbed, or the unit cannot be correctly adjusted as outlined under "Placing In Service", it must be completely recalibrated as outlined under "Basic Alignment"

No calibration of the booster is required

NOTE For maximum accuracy, the Function Generator should be calibrated in the same position as that of final installation

Also, it is suggested that an extra controller mounting assembly (part no 5327136-1) be used when calibrating in order to eliminate disruption of piping

The Function Generator consists of two major assemblies, the Controller and the Gam Servo Assembly Each assembly must be calibrated separately If it has been necessary to repair or replace parts in either assembly, the basic alignment of the unit can be re-established by following the applicable procedure outlined below After the individual section has been realigned, it will be necessary to repeat the steps outlined under "Placing n Service" to adjust the complete Function Generator for the required service

Basic Alignment (Parts Drawing P92 11 1)

- 1 Remove plastic cover from unit
- 2 Remove plastic plugs from seven ports in controller mount
- 3 Check to be sure that A/B and C/D beams are parallel to each other and to edge of control ler base, and that hinge (item 33) is straight
- 4 Check alignment of linkage pivot pin (42) End of pivot pin should be in line with dimple in shaft of range adjustment (50)
- 5 Check to see that nozzle on C/D beam is in center of vane (2), and vane body (4) is in contact with pivot pin (42)

6 Check to be sure that A/B and C/D bias adjustments springs (20) are parallel to edge of controller base, and that A/B and C/D bias spring assembly locknuts (65) are tight

7 Place direct/reverse switch (25) in "D" position

8 Place P/P+I switch, located next to integral valve chamber on controller base, in "P" position

9 Place on-off switch, located next to booster assembly, in "1" position

10 Apply 9 psig (62 kPa) + 01 to E4 port

11 Check to see that servo beam is approximately parallel to the servo mounting base (22) If necessary, loosen two nuts retaining servo spring assembly (17) and reposition nuts on spring assembly until servo beam is parallel to mounting base Re-tighten nuts

12 Adjust E4 input to 15.5 psig (106.9 kPa) ± 01

13 Loosen nut retaining stop screw (45) and adjust position of screw until screw head just contacts servo beam Re-tighten nut to retain stop screw

14 Adjust E4 input to 2.0 psig (13.8 kPa) + 01

15 Adjust position of elastic stop nut (25) until nut just contacts underside of servo beam

16 Turn on supply pressure to provide 18 psig (124 kPa) to unit

Leak Test

- 1 Rotate pinion gear to gain of 1
- 2 Adjust E1 and E4 inputs to 15 psig (103.4 kPa) + 01
- 3 Adjust C/D bias screw on unit until output equals 15 psig + 01
- 4 Using liquid leak detector, check unit for leaks Check all O-rings, gasketed joints, bellows ends and tubing connections

Low Rise Template Calibration

- 1 Disconnect air supply to "S" connection

2 Loosen knurled nut (Parts Drawing P92 12 1, item 8) on template hub approximately one turn Grasp hub (7) to prevent it from turning and adjust eccentric screw on hub until hub driven arm is approximately in mid position of its adjustment range Do not retighten knurled nut

3 Adjust E4 input to 9 psig + 01

4 Adjust zero screw (40) to provide a clearance of approximately 1/16 inch (1.6 mm) between zero adjustment arm (15) and servo beam (24)

5 Check to see that servo beam is approximately parallel to servo mounting base (22) If necessary, loosen two nuts retaining servo spring assembly (17) and reposition nuts on spring assembly until servo beam is parallel to mounting base Retighten nuts

6 Adjust zero screw (40) on servo beam until center line of driven arm on template hub is approximately parallel to servo mounting base

NOTE Do not turn zero screw more than three turns in either direction If required parallel between servo beam and servo mounting base can not be obtained with less than three turns of zero screw, reset screw to provide a clearance of 1/16 inch (1.6 mm) between zero adjustment arm and servo beam Repeat step 5, above

7 Install low rise template between clamp disc and template hub and push template into hub assembly until template bottoms against center bushing in hub Install template in hub assembly so that word "direct" on template can be read correctly Rotate template until mid-travel markings are aligned with nozzle on nozzle support (5) Lightly tighten knurled nut to retain template

8 Apply 18-20 psig to "S" connection

9 Recheck alignment of nozzle with mid travel markings on template If necessary, loosen knurled nut on hub assembly and reposition template to align nozzle and template mid-travel line

10 Adjust E4 input as required to rotate template until largest radius line on template is in line with nozzle Loosen nozzle retaining

screw (46) and adjust nozzle (6) to provide .002 (0.05 mm) to .005 (0.13 mm) inch clearance between nozzle and template Retighten retaining screw

11 Adjust E1 input to 10 psig + 01 and E4 input to 9 psig + 01

12 Slightly loosen two hex head cap screws retaining nozzle support on gain arm and rotate gain arm until output equals 10 psig + 01 Retighten cap screws to retain nozzle support in this position and recheck output If necessary, loosen two cap screws and readjust gain arm setting Repeat until output is 10 psig + 01, with nozzle support secured on gain arm

13 Adjust E1 and E4 inputs to 3 psig + 01 Output should equal 3 psig + 06 If output is 3 psig + 06, proceed to step 14 If output is not 3 psig + 06, recheck null adjustment of unit by repeating "Null Procedure"

14 Change E4 input from 3 psig to 9 psig + 01, 15 psig + 01, and then back to 9 psig + 01 and observe output at each point Output must remain constant at 3 psig + 06 (± 0.05 of span)

15 If output remains constant at 3 psig ± 0.06 , proceed to step 17

If output varies as E4 input is changed from 3 to 15 psig (20.7 to 103 kPa), adjust E4 to 3 psig ± 0.01 Adjust null screw on gain arm until output equals 3 psig + 0.06 If output is higher than 3 psig, turn null screw clockwise If output is lower than 3 psig, turn null screw counter clockwise

16 Repeat steps 14 and 15 until output remains constant at 3 psig + 0.06 as E4 input is changed from 3 to 15 psig

17 Adjust E1 input to 10 psig ± 0.01 Adjust E4 input to 9 psig + 01

18 If necessary, adjust C/D bias screw until output equals 10 psig + 01

19 Adjust E4 input to 3 psig + 01

20 Adjust eccentric screw on template hub assembly until output equals 8.60 psig (59.3 kPa) ± 0.12 (.83), and nozzle is aligned as closely as possible with minimum radius line on template

NOTE Adjust eccentric screw to correct output signal pressure rather than nozzle position on template

21 Adjust E4 input to 15 psig + 01

22 With E4 input adjusted to 15 psig + 01, output should equal 11 40 psig (78 6 kPa) + 12 (83) and nozzle should be aligned as closely as possible with maximum radius line on template

If output pressure is lower than 11 40 psig +0 12, loosen knurled nut on template hub, rotate template a few degrees counterclockwise, and lightly retighten knurled nut

If output pressure is higher than 11 40 psig +0 12, loosen knurled nut on template hub, rotate template a few degrees clockwise, and lightly retighten knurled nut

23 Following any rotation of template, adjust E4 input to 9 psig + 01 Adjust zero screw on servo beam until output equals 10 psig + 0 12 and nozzle is aligned as closely as possible with mid radius line on template

NOTE Adjust zero screw to correct output pressure rather than nozzle position on template

24 Repeat steps 19 through 23 until output signal pressures are correct within +0 12 psig (+1 0% of span) and nozzle is aligned as closely as possible with radius line on template, for each E4 input

25 When output pressure for each E4 input is correct, securely tighten knurled nut to retain template. Recheck calibration by repeating steps 19 through 23. If necessary "touch up" calibration with knurled nut tightened.

26 When output pressure for each E4 input is correct with knurled nut and all other fasteners tightened securely, low rise template calibration is complete.

NOTE If reverse action of E4 input is desired, template must be installed in hub assembly so that word reverse on template can be read correctly. Also, outputs required for E4 inputs of 3 psig and 15 psig will be reversed from order listed in steps 19 thru 22. Finally, direction template must be rotated in order to correct output pressure when E4 15 psig. will be

opposite of that listed in step 21. For example, if output is lower than 11 40 psig +0 12 when E4 input is 15 psig, template must be rotated counterclockwise, and vice versa.

High Rise Template Calibration

1 Disconnect air supply to "S" connection

2 Loosen knurled nut (Parts Drawing P92 12 1, item 8) on template hub approximately one turn. Grasp hub (7) to prevent it from turning and adjust eccentric screw on hub until hub driven arm is approximately in mid position of its adjustment range. Do not retighten knurled nut.

3 Adjust E4 input to 9 psig + 01

4 Adjust zero screw (40) to provide a clearance of approximately 1/16 inch (1 6 mm) between zero adjustment arm (15) and servo beam (24).

5 Check to see that servo beam is approximately parallel to servo mounting base (22). If necessary, loosen two nuts retaining servo spring assembly (17) and reposition nuts on spring assembly until servo beam is parallel to mounting base. Retighten nuts.

6 Adjust zero screw (40) on servo beam until center line of driven arm on template hub is approximately parallel to servo mounting base.

NOTE Do not turn zero screw more than three turns in either direction. If required parallel between servo beam and servo mounting base can not be obtained with less than three turns of the zero screw, reset zero screw to provide clearance of 1/16 inch (1 6 mm) between zero adjustment arm and servo beam. Repeat step 5, above.

7 Install high rise template between clamp disc and template hub and push template into hub assembly until template bottoms against center bushing in nut. Install template in hub assembly so that part number on template can be read correctly. Rotate until the mid travel markings on template are aligned with nozzle on nozzle support (5). Lightly tighten knurled nut to retain template.

8 Apply 18 20 psig air supply to "S" connection

9 Recheck alignment of nozzle with mid travel markings on template. If necessary, loosen knurled nut on template hub assembly and reposition template to align nozzle and template mid travel line.

10 Adjust E4 input as required to rotate template until largest radius line on template is in line with nozzle. Loosen nozzle retaining screw (46) and adjust nozzle (6) to provide .002 (.05 mm) to .005 (.13 mm) inch clearance between nozzle and template. Re-tighten retaining screw.

11 Adjust E1 input to 7 psig + 01 and E4 input to 9 psig + 01.

12 Slightly loosen two hex head cap screws retaining nozzle support on gain arm and rotate gain arm until output equals 10 psig + 01. Re-tighten cap screws to retain nozzle support in this position and recheck output. If necessary, loosen two cap screws and readjust gain arm setting. Repeat until output is 10 psig + 01 with nozzle support secured on gain arm.

13 Adjust E1 and E4 input to 3 psig ± 01. Output should equal 3 psig + 06. If output is 3 psig + 06, proceed to step 14. If output is not 3 psig + 06, recheck null adjustment of unit by repeating "Nulling Procedure".

14 Change E4 input from 3 psig to 9 psig + 01, 15 psig + 01, and then back to 9 psig + 01 and observe output at each point. Output must remain constant at 3 psig + 06 (+0.5% of span).

15 If output remains constant at 3 psig + 06, proceed to step 17.

If output varies as E4 input is changed from 3 to 15 psig, adjust E4 input to 3 psig ± 01. Adjust null screw on gain arm until output test gage indicates 3 psig + 06. If output is higher than 3 psig, turn null screw clockwise. If output is lower than 3 psig, turn null screw counter-clockwise.

16 Repeat steps 14 and 15 until output remains constant at 3 psig + 06 as E4 input is changed from 3 to 15 psig.

17 Adjust E1 input to 7 psig + 01. Adjust E4 input to 9 psig + 01.

18 If necessary, adjust C/D bias screw until output equals 10 psig + 01.

19 Adjust E4 input to 3 psig + 01.

20 Adjust eccentric screw on template hub assembly until output equals 5.0 psig + 0.12, and nozzle is aligned as closely as possible with minimum radius line on template.

NOTE: Adjust eccentric screw to correct output signal pressure rather than nozzle position on template.

21 Adjust E4 input to 15 psig + 01.

22 With E4 input adjusted to 15 psig + 01, output should equal 15.0 psig + 0.12 and nozzle should be aligned as closely as possible with maximum radius line on template.

If output pressure is lower than 15.0 psig + 0.12, loosen knurled nut on template hub, rotate template a few degrees counterclockwise, and lightly re-tighten knurled nut.

If output signal pressure is higher than 15.0 psig + 0.12, loosen knurled nut in template hub, rotate template a few degrees clockwise, and lightly re-tighten knurled nut.

23 Following any rotation of template, adjust E4 input to 9 psig + 01. Adjust zero screw on servo beam until output equals 10 psig + 0.12, and nozzle is aligned as closely as possible with mid radius line on template.

NOTE: Adjust zero screw to correct output signal pressure rather than nozzle position on template.

24 Repeat steps 19 through 23 until output pressures are correct within +0.12 psig (±1.0% of span) and nozzle is aligned as closely as possible with radius line on template, for each E4 input.

25 When output pressure for each E4 input is correct, high rise template calibration is complete.

26 Securely tighten knurled nut to retain template. Recheck calibration by repeating steps 19 through 23. If necessary, "touch up" calibration with knurled nut tightened.

Template Shaping Routine

Necessary Tools

- 1 Table showing desired input/output relationship
- 2 Fine tip pen and pencil for marking blank template
- 3 Engineering curve for drawing desired curve
- 4 Sharp scissors for accurate cutting of template
- 5 Hand regulator for manual operation of gain servo air cylinder

Preparation for Template Shaping

1 Mount Function Generator and complete piping as outlined under "Installation" Complete "Nulling Procedure" under "Placing In Service"

2 Apply mid range pressure to E4 connection, 9 psig (62 kPa) for 3 to 15 psig (20.7 to 103 kPa) range and adjust servo zero screw (Parts Drawing P92 12 1, item 40) to make driver arm of template hub perpendicular to connecting link Adjust hub eccentric to mid position

3 Loosen elastic stop nut, washer, knurled nut and template clamp plate, and install template, printed side up, so that mid travel mark lines up with nozzle hole

4 Tighten knurled nut

5 Change E4 signal from 3 to 15 psig and check that template swing is approximately 80° or 0 to 100% of travel lines If not, adjust eccentric in template hub

6 Readjust servo zero screw, if necessary, to realign template mid travel mark with nozzle hole

7 Disconnect flexible hose (item 31) from cylinder base and plug or clamp hose

8 Connect hand regulator to cylinder and apply pressure Piston movement may be sluggish and exact positioning may require nozzle support to be lightly tapped Cylinder input is

now external Servo feedback is, therefore, in operative allowing nozzle to be positioned anywhere on template

9 Loosen two hex head cap screws (item 47) retaining nozzle support to sector arm and rotate sector arm to position where it will operate over proper gain range

10 Retighten screws

11 Determine extreme output conditions from a table of input/output values and apply desired input for each extreme condition

12 Adjust cylinder pressure to obtain desired output to make sure gain span is within 34° sector arm swing

13 Change input signal in 10% steps (5% steps may be required for complex template shapes and steep slopes) At 3 psi (20.7 kPa) adjust cylinder input pressure to whatever pressure is necessary to read required output

14 Mark with pencil thru template guide and repeat process for each increment of input/output table

15 When all points have been plotted, remove template from hub

16 Use engineering curve and fine tip pen to connect penciled marks in a smooth curve When drawing template curve remember that nozzle must be slightly more obstructed by template with larger radius in order to maintain greater back pressure Therefore, make scribed line pass about .005 outside center of marks at maximum and .005 inside at minimum Line should be centered on dots at center of curve

17 Replace template under hub clamp plate making sure template is tight against bushing

18 With 9 psi signal at E4, align template mid travel mark with nozzle hole Servo zero screw can be used to make this adjustment exact

19 Disconnect hand regulator from cylinder and reconnect tubing

The Function Generator should now be functional Minor adjustment to the servo should complete the calibration if the template has been cut accurately

Mini Line 520 Function Generator, Type FG

TROUBLESHOOTING

If the Function Generator is inoperative or if operation is faulty, check the calibration as outlined under "Complete Calibration", and perform operations listed under "Routine Maintenance." If operation is still faulty perform a visual check for loose screws, damaged or broken parts, leaks etc. The Fault Correction Chart lists most common problems and corrective actions.

WARNING TEST GAGE SHOULD NORMALLY BE USED ONLY TO TROUBLESHOOT A FAULTY SYSTEM THAT IS NOT IN AN OPERATING MODE. PROBE INSERTION CAUSES A PNEUMATIC SIGNAL "BUMP" WHICH COULD CAUSE SERIOUS SYSTEM UPSET.

AVERTISSEMENT IL NE FAUT UTILISER LA JAUGE D'ESSAI QUE POUR DETECTER UNE PANNE SUR UN CIRCUIT DEFECTUEUX QUI N'EST PAS EN COURS DE FONCTIONNEMENT. L'INSERTION DE LA SONDE PROVOQUE UN "COGNEMENT" DU SIGNAL PNEUMATIQUE QUI RISQUE DE CAUSER UN DEREGLAGE SERIEUX DU SYSTEME.




FIGURE 5 Mounting and Test Gage Attachment

Test Gage Kit (Figure 5)

A test gage (part no 5328485 1) is available as an accessory to aid in troubleshooting the pneumatic control system. The kit consists of a gage, tubing and a test probe. Slowly attach the test gage probe to a test jack and read pressure. After reading, remove probe and replace jack cap and unit cover.

Pneumatic Booster (Figure 6)

No calibration or adjustment of the booster is required.

In normal operation the booster is inaudible. However, if the core and the valve plug seat of the output section are not aligned or the valve plug is not seated properly, the booster will produce a hissing sound. If this occurs the booster should be removed from the unit and replaced.




FIGURE 6 - Pneumatic Booster

FAULT CORRECTION CHART

Fault	Cause	Correction
Controler inoperable	a No air supply b Booster orifice clogged c Vane not touching nozzle d Dirty air supply e Incorrect switch position f Worn base grommet (mounting base ar valves closed)	a Check supply connect on b Press orifice cleanout plunger (See Note 1) c Adjust C/D bases d Check operation of booster e See Figure 2 and correct f Replace grommet
Controler unstable	a Fasteners loose b Insufficient pre-load on linkage pivot pin	a Tighten fasteners b Slightly open center of valve
Beows cannot be balanced	a Beam hinge bent b Damaged beows	a Replace hinge b Replace beows
Controler output goes to zero	a Booster orifice clogged	a Press orifice cleanout plunger (See Note 1)
Controler output goes to supply pressure	a Blocked passages from booster unit to nozzle	a Clean and blow out passages
Poor accuracy	a Beows not balanced b Vane pad not centered at null pressures	a Balance beows b Center vane pad
Poor sensitivity	a Vane pad not perpendicular to nozzle b Booster bleed orifice clogged c Vane pad not centered at null pressures d Leakage - input lines or test jacks	a Re-position linkage b Clean manually at orifice where c Center vane pad d Check with leak detector and repair
Slow response	a Restrictors under D/R switch clogged	a Clean D/R switch
High hysteresis	a Loose fasteners - including beows set screws	a Tighten beows set screw
Gain changes (high or low)	a Range gain - adjust shaft sufficiently to 'zero'	a Retorque (See Note 2)
Setpoint changes with integral adjustment	a Leak at integral valve E3 connection or C beows	a Check and repair
Integral time not equal both directions	a Leak beyond integral valve (C beows) or E3 connection	a Check and repair
Derivative time not equal both directions	a Leak at derivative valve or D beows	a Check and repair passage or beows
Booster output pressure does not immediately increase when nozzle back pressure is increased	a Clogged orifice b Leakage around sections of casting c Dirty filters in mounting base	a Press orifice cleanout plunger (See Note 1) b Remove booster and retorque screws c Remove and replace filters
Booster output pressure does not immediately decrease when nozzle back pressure is reduced	a Blocked air passages from booster unit to nozzle b Internal leakage of booster	a Clean air passages b Replace booster

Notes: 1 Press orifice cleanout plunger only when equipment is not operating. See WARNING under 'Routine Maintenance'
2 Overturning will increase in hysteresis

FAULT CORRECTION CHART (continued)

Fault	Cause	Correction
Gain Servo Cylinder - Remains extended - Extends fast, retracts slow Does not retract fully	a) Supply pressure too high b) Leakage past orifice assembly c) Nozzle not plugged d) Cylinder preloaded spring not tight enough e) Contamination in cylinder	a) Correct to 18 to 20 psig (124 to 138 kPa) b) Check O-ring and O-ring seating surface c) Clean or blowout d) Readjust e) Replace cylinder/piston assembly
Remains retracted Retracts fast, extends slow Will not extend fully	a) Low supply or clogged filter in supply port b) Valve stem in supply port controller mounts not actuated fully c) Leakage from nozzle back pressure chamber or passage d) Plugged orifice in cylinder base e) Piston/cylinder clearance too great f) Preload spring too tight g) Misshaped nozzle face h) Nozzle not preloaded against template	a) Correct to 18 to 20 psig, install new filter pad (supply) b) Check controller's pushed as far as possible into mount c) Check for leaks at orifices Plug tube fittings, cylinder base d) Clean orifice in cylinder base e) Replace cylinder/piston assembly f) Readjust g) Replace nozzle h) Preload nozzle against template at minimum radius, check nozzle temperature guide clearance
Hysteresis and non repeatability (See Note 3)	a) Loose bellows assembly b) Interference between bellows beam and temperature assembly linkage c) Interference between template and nozzle or temperature guide d) Connecting rod preloaded too high	a) Tighten bellows set screw b) Straighten linkage to eliminate binding c) Remove burrs from temperature and/or adjust temperature guide d) Adjust rod pivot preload
Instability (See Note 3)	a) Piston/cylinder interference b) Gain arm bearing preload too high c) Nozzle/temperature guide clearance	a) Replace cylinder/piston assembly b) Readjust c) Readjust nozzle/temperature guide clearance

Note 3 Instability, hysteresis and non repeatability are interrelated Causes and corrections therefore, will also be interrelated

OPERATION

Operation of the function generator is shown schematically in Figure 8 and in block form in Figure 7

Gain Control Mechanism

The gain adjusting servo uses a piston within an air cylinder to provide the power necessary to move the controller sector arm. The air cylinder is controlled by the gain servo nozzle which is attached to the sector arm. The servo nozzle and air cylinder provide a closed loop motion servo which positions the sector arm so that the nozzle is at the edge of the template. The nozzle functions like the roller on a conventional template follower except that it is not limited by steep template rises or abrupt contour changes. The nozzle also produces no force against the template permitting it to be made of easily cut polyester film. The template is positioned by the E4 gain control signal acting through the gain servo bellows beam and connecting link. Shape determines the sector arm position as a function of the gain control signal. A built in guide permits marking of a blank template, exactly in line with the nozzle to facilitate custom shaping.

Controller Mechanism

The controller A/B beam moves in proportion to the difference in pressure between the A and B bellows. This pressure difference provides a subtraction function or a comparison of one signal to a set point. The A/B beam motion

is coupled to a vane through an adjustable four bar linkage. This linkage allows vane motion toward or away from the controller nozzle providing adjustable gain. Gain of the four bar linkage depends upon A/B beam and sector arm position.

For a given sector arm position a movement of the A/B beam will produce a movement at the vane toward the nozzle proportional to gain at that sector arm position. Conversely, for a given A/B beam position, rotation of the sector arm will produce a movement at the vane proportional to the degree of unnulling. (Null condition is defined as the state at which a sector arm movement will have no effect on vane position or output.) In either case, vane motion toward or away from the controller nozzle will cause a corresponding increase or decrease in nozzle backpressure.

Backpressure change is amplified by a booster and fed to the D bellows and to the output connection as a 3.15 psig (20.7 to 103 kPa) signal. At the D bellows, the signal repositions the C/D beam to restore the nozzle to its at balance distance from the vane.

Derivative action can be obtained by placing an external bleed valve/volume chamber in the input signal line (Figure 8). Integral action can be obtained by placing an external bleed valve/volume chamber between the output and C bellows (Figure 8).




FIGURE 7 Function Generator Block Diagram

Mini-Line 520 Function Generator, Type FG




FIGURE 8 - Schematic Diagram of Pneumatic Function Generator, Type FG

EXPLANATION OF NOMENCLATURE

Digit 1 2 3	Description
FG 1 1	Pneumatic Function Generator
↓	Proportional Control Action
1	3 to 15 psig (20.6 to 103 kPa)
5	Linear Temperature Characteristic Customized Temperature Characteristic

SPECIFICATIONS

Accuracy†	±1% of output span (calibrated to ±50% of output span)
Input Signal Range	3 to 15 psig (20.7 to 103 kPa)
External Connections	1/8 inch 27 NPT female connections
Normal Operating Conditions	Ambient Temperature 40° to 140°F (4.4 to 60°C) Ambient Temperature Effect -2% maximum of output span over 100°F (55.6°C) temperature span
Repeatability	0.25%
Deadband	0.25% of output span
Air Supply	18 to 20 psig (124 to 138 kPa) supply pressure nominal
Air Consumption	15 scfm (4.2 x 10 ⁻⁴ M ³ /S) at balance
Supply Pressure Effect	-15% of output span per 1 psig
Supply and Exhaust Capacity	1.0 scfm (4.72 x 10 ⁻⁴ M ³ /S) for 1 psig (6.89 kPa) change in output at midrange 9 psig (62 kPa)

Position Sensitivity	±1% of span for 30° rotation in any direction from preferred mounting position
Vibration	Tested in accordance with MIL-STD 167B (sh ps)
Mounting	Indoor wall or rack mounted in the indicated position only
Materials	Bronze bearings aluminum bearings and frame, Buna-N O-rings Beryllium Copper linkage polyester film templates
Weight	Net 9.3 lbs (4.22 kg) Shipping 12 lbs (5.45 kg)
Gain Range	1 to 10.0
Factory Calibration	Standard Low range temperature installed to provide gain change of 0.8 to 1.2 direct acting 3 psig (20 kPa) nominal Specified Calibration not specified as standard input vs output or input vs gain data must be furnished for custom temperature shipping (spec a functions)

†As defined by SAMA Standard PMC20 1

NOTE A data at midrange reference condition
Temperature 75°F (41.5°C) ±5°F (±5.6°C)

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

REPLACEMENT PARTSOrdering Individual Parts

The following drawings are Parts Drawings for the Type FG Pneumatic Function Generator and its spare parts kits. Items with part numbers may be ordered separately. Items with kit numbers (without separate part numbers) must be ordered by the kit number in which they are included.

Normally, these drawings apply to the unit furnished. However, there may be individual differences in specific units because of

a design changes made since the printing of this instruction section, or

b special design of the unit to make it suitable for a special application.

Therefore, when ordering individual parts or kits, assure the receipt of correct replacements by specifying on the order

a complete nomenclature and series number of equipment for which parts are desired, and

b the Parts Drawing number and title on which each part is illustrated.

Recommended Spare Parts

The following listed spare parts kits should be stocked in the quantities listed.

KIT NO	NAME	QUANTITY
258141 1	BOOSTER	1
258142 1	A B BELLOWS	1
258143 1	C D BELLOWS	1
258146 1	FILTER	1
258152 1	COVER	1
258148 1	O RING REPLACEMENT	1
258150 1	CYLINDER	1

Accessories

The following accessories are recommended.

PART NO	NAME	QUANTITY	COMMENTS
5327136 1	Control Mount	1	Plug in mount to be used for calibrating controler base assemblies.
5328485 1	Test Probe Kit	1	Assembly (gage, tubing test connector) for controlling monitoring, and adjustment, calibration and performance checks.
5324066 1	Valve Core	1	Extra air trapping valve for output connection.

Options

PART NO	NAME	QUANTITY	COMMENTS
5316733 1	Volume Chamber and B Reed Valve	1	For adding external integrate (reset) or derivative rate.


Mini-Line 520 Function Generator, Type FG

Bailey Meter Company, Wickliffe Ohio 44092, a subsidiary of Babcock & Wilcox, U S A

*Bailey Meter Australia Pty Ltd, Regents Park, N S W, Australia
Bailey do Brasil, Sao Paulo, Brazil
Bailey Meter GMBH Mannheim West Germany*

*Bailey Meter Company Ltd Pointe-Claire Quebec, Canada
Bailey Japan Company, Ltd Nirayama cho, Japan
Representatives in Other Principal Cities*

CONTROLLER ASSEMBLY PART NO. 5327000-□



D5327000J

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

Parts Drawing P92-11-1 Controller Assembly

ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	5327774 1	SCALE MOUNT NG PLATE SEE TABLE	31	19734 18	WASHER, SEE TABLE	57		190 32x 500 LG HEX HD STN STL SEMS EXT 4 REQD
2	K T NO 258144 1	ADJUSTABLE VANE END	32	5326970 1	CLAMP PLATE, 4 REQD	58		086 56x 125 LG PAN HD STN STL MACH SCR, 4 REQD
3	SEE TABLE	CONTROLLER BASE ASSEMBLY	33	5326969 1	SPR NG H NGE SEAL WASHER	59		086 56x 250 LG PAN HD STN STL MACH SCR, 4 REQD
4	5327058 1	VANE BODY	34	26126 1	TUBE F TT NG COMPRESS ON CL P 2 REQD	60	K T NO 258142 1	112-40x 188 LG HEX SOC HDLS STN STL CONE PT SET SCR, 4 REQD
5	SEE TABLE	C D B AS SPR NG ASSEMBLY	35	26002 1	NOZZLE TUBING RANGE ADJUSTMENT SHAFT CLAMP	61	K T NO 258144 1	086 BRASS FLAT WASHR
6	5326981 1	B AS ADJUSTMENT SCREW, 2 REQD	36	1951049 3	RAT O L NK SUPPORT	62		190 32x 375 LG F L HD STN STL MACH SCR, 3 REQD
7	5326980 1	DR VE L NK	37	1951567 1	RET A N NG R NG, SEE TABLE	63		190 32x 375 LG HEX HD STN STL CAP SCR 8 REQD
8	5327055 1	H NGE CLAMP 2 REQD	38	5316156 1	P N ON SEE TABLE	64		250 28 STN STL REG HEX JAM NUT, 6 REQD
9	1962928 1	SERV CE LEGEND	39	5327771 1	P N ON SEE TABLE	65	K T NO 258144 1	1202-00 STN STL SHKPRF LKWSHR 138 32x 312 LG PAN HD STN STL MACH SCR
10	5326974 1	NULL ADJUSTMENT SCREW	40	197480 25	TH N NUT, 4 REQD	66		138 32x 312 LG PAN HD STN STL MACH SCR 2 REQD
11	5326975 1	C D BEAM ASSY	41	5326995 1	AND K T NO 258143 1	67		190 32x 375 LG F L HD STN STL MACH SCR, 2 REQD
12	K T NO 258143 1	C D BELLOWS ASSEMBLY, 2 REQD	42	5316891 1	AND K T NO 258143 1	68		190 32x 375 LG F L HD STN STL MACH SCR, 2 REQD
13	5327790 1	INTEGRAL VALVE ASSEMBLY, SEE TABLE	43	K T NO 258142 1	AND K T NO 258143 1	69		190 32x 375 LG F L HD STN STL MACH SCR, 2 REQD
15	197480 18	RET A N NG R NG, SEE TABLE	44	K T NO 258142 1	AND K T NO 258143 1	70	K T NO 258144 1	086 56 BRASS HEX NUT
16	452219 3	SEAL NG SCREW, SEE TABLE	45	67125 10	SPR NG WASHER 4 REQD	71		250 20x 500 LG PAN HD STN STL MACH SCR 4 REQD
17	5320657 1	ON-OFF SW TCH ASSY 2 REQD	46	K T NO 258141 1	GROMMET			
19	K T NO 258148 1	O R NG, 4 REQD	47	K T NO 258141 1	O R NG			
20	5326956 1	SPR NG B AS ADJUSTMENT 2 REQD	48	KIT NO 258141 1	O R NG 3 REQD PNEUMATIC BOOSTER			
23	5326957 1	A B BIAS SPR NG ASSEMBLY	49	5326986 1	RAT O L NK RANGE ADJUSTMENT			
24	K T NO 258142 1	A B BELLOWS ASSY 2 REQD	50	5326992 1	ADJUSTMENT SCALE SEE TABLE			
25	5320658 1	D RECT REVERSE SW TCH ASSY	51	5327064 2	CLAMP PLATE 2 REQD			
26	5326976 1	A B BEAM	53	5327114 1	190 32x 750 LG F L HD STN STL MACH SCR, SEE TABLE			
27	5326959 1	VOLUME CHAMBER SEAL SEE TABLE	55		086 STN STL REG SPRG LKWSHR, 6 REQD			

NOTE TEMS W TH PART NUMBERS MAY BE ORDERED SEPARATELY TEMS W TH K T NUMBERS W THO_T SEPARATE PART NUMFRS MUST BE ORDERED BY THE K T NUMBER N WH CH THEY ARE INCLUDED


PART NO	ITEMS 1,15,31,40,41,51	ITEM 3	ITEM 5	ITEMS 13,27	ITEM 16	ITEM 55	ITEM 63
5327000 1 (PROP ACT ON)	1	5326961 1	5327115 1	OM T	1	OM T	13
5327000 2 (P + 1 ACT ON)	1	5326961 1	5327115 1	1	OM T	4	17
5327000 3 (PROP ACT ON FOR FUNCT ON GENERATOR)	OM T	5326961 2	5327111 1	OM T	1	OM T	13

Bailey Meter Company, Wickliffe Ohio 44092, a subsidiary of Babcock & Wilcox, U S A

Bailey Meter Australia Pty Ltd Regents Park, N S W Australia
 Bailey do Brasil, Sao Paulo, Brazil
 Bailey Meter GMBH, Mannheim, West Germany

Bailey Meter Company Ltd Pointe-Claire, Quebec, Canada
 Bailey Japan Company Ltd, Nriyama-cho, Japan
 Representatives in Other Principal Cities

GAIN SERVO ASSEMBLY PART NO. 5327700-□



D5327700C

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

12-1 Gain Servo Assembly

ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
3	5327000 3	CONTROLLER ASSY	23	5327730 1	H NGE ASSY	42		112-40 STL HEX NUT
4	5327741 1	LOW R SE CAM	24	KIT NO	BEAM & BELLOW	43		190 32x 375 LG F L HD
5	5327713 1	NOZZLE SUPPORT		258151A1	ASSY			STN STL MACH SCR, 7
6	5327729 1	NOZZLE	25	197120 5	ELAST C STOP NUT			REQD
7	5327743 1	CAM HIJ ASSY	26	5327726 1	L NK	44	K T NO	112-40x 188 LG HEX
8	5327735 1	KNURLED NUT	27	5327725 1	FLAT SPR NG		258151A1	SOC HDLS STN STL
9	197120 26	ELAST C STOP NUT	28	5327727 1	CAM GUIDE			CONE PT SET SCR
10	5327715 1	PRELOAD SPR NG	29	K T NO	TUBE F TT NG 4 REQD	45		190 32x2 500 LG PAN HD
11	19734-41	SMALL WASHER		258150A1				STL MACH SCR
12	5327718 1	CLAMP PLATE	30	1951567 2	NOZZLE TUB NG	46		112-40x 500 LG PAN HD
13	1943785-3	CABLE T E	31	1951567 3	NOZZLE TUB NG			STN STL SEMS EXT
14	451871 2	WASHER	32	5327698 1	GAIN DECAL	47		190-32x 375 LG HEX HD
15	5327738 1	ZERO ADJUSTMENT	33	K T NO	COMPRESS CL P, 4			STN STL CAP SCR, 3
		ARM		258150A1	REQD			REQD
16	5327689 1	CONNECT NG ROD	34	K T NO	SEAL WASHER, 4 REQD	48		375 16 SEM F N STN STL
17	5327733 1	SPR NG ASSY		258150A1				REG HEX JAM NU
18	K T NO	CYL NDER ASSY	38		086 56x 188 LG PAN HD	49		125x 281x 025 PLA N
	258150A1				STL SEMS NT 2 REQD			BRASS WASHER
19	5327690 1	SPR NG	39		190 32 STL HEX NUT	50		190 STN STL REG
20	K T NO	O R NG			4 REQD			SPR NG LOCKWASHER
	258151A1		40		086 56x 375 LG PAN			8 REQD
21	K T NO	O R NG			HD STL MACH SCR	52		203x 406x 040 PLA N
	258148A1		41		112-40x 875 LG PAN HD			STL WASHER, 3 REQD
22	5327707 1	MTG BASE			STL MACH SCR	53		094x 250x 032 PLA N
								BRASS WASHER


Note: Items with part numbers may be ordered separately. Items with kit numbers (without separate part numbers) must be ordered by the kit number in which they are included.

Bailey Meter Company, Wickliffe Ohio 44092, a subsidiary of Babcock & Wilcox, U S A

Bailey Meter Australia Pty Ltd, Regents Park, N S W, Australia
 Bailey do Brasil, Sao Paulo, Brazil
 Bailey Meter GMBH Mannheim, West Germany

Bailey Meter Company Ltd Pointe-Claire Quebec Canada
 Bailey Japan Company, Ltd Nirayama-cho Japan
 Representatives in Other Principal Cities

TYPE FG FUNCTION GENERATOR PART NO. 532775-□



D532775F

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

192-12-2 Function Generator, Type FG

ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	5327136 1	CONTR MOUNT	8	K T NO	O R NG GASKET 2
2	K T NO	SEAL NG CORD 34 '		258152A1	REQD
	258152A1		9	K T NO	SCREW, COVER
3	5327700 1	GA N SERVO ASSY		258152A1	
4	K T NO	COVER	10	K T NO	SCREW COVER
	258152A1			258152A1	
5	5327741 2	H GH R SE CAM	11	1962929 1	NAMEPLATI
6	5327741 3	BLANK CAM 2 REQD	13		219x 500x 049 PLA N
7	KIT NO	RETA N NG R NG, 2			STN STL WASHER
	258152A1	REQD	14		190 32x 500 LG PAN
					HD STN STL MACH SCR


Note: Items with part numbers may be ordered separately. Items with kit numbers (without separate part numbers) must be ordered by the kit number in which they are included.

Bailey Meter Company, Wickliffe Ohio 44092, a subsidiary of Babcock & Wilcox, U S A

Bailey Meter Australia Pty Ltd, Regents Park N S W Australia
 Bailey do Brasil, Sao Paulo, Brazil
 Bailey Meter GMBH, Mannheim, West Germany

Bailey Meter Company Ltd, Pointe-Claire, Quebec, Canada
 Bailey Japan Company Ltd, Nirayama-cho, Japan
 Representatives in Other Principal Cities

**MINI-LINE 520 PNEUMATIC COMPUTER/CONTROLLER,
TYPE FC AND FUNCTION GENERATOR, TYPE FG
BOOSTER SPARE PARTS
KIT NO. 258141-1**




A7018

ITEM	NAME	QUANTITY
1	BOOSTER	1
2	O RING	3
3	O R NG	1

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

MINI-LINE 520 PNEUMATIC COMPUTER/CONTROLLER, TYPE FC AND FUNCTION GENERATOR, TYPE FG A-B BELLOWS SPARE PARTS KIT NO. 258142-1




A7019

ITEM	NAME	QUANTITY
1	BELLOWS ASSEMBLY	1
2	O R I N G	1
3	S P R I N G W A S H E R	1
4	T H I N N U T	1
5	112-40x188 LG HEX SOC HDL S T N S T L C O N E P T S E T S C R	1

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

**MINI-LINE 520 PNEUMATIC COMPUTER/CONTROLLER
TYPE FC AND FUNCTION GENERATOR, TYPE FG
C-D BELLOWS SPARE PARTS
KIT NO. 258143-1**




A7021

ITEM	NAME	QUANTITY
1	BELLOWS ASSEMBLY	1
2	O R I N G	1
3	SPR I N G W A S H E R	1
4	T H I N N U T	1
5	112.40x 188 LG HEX SOC HOLDS STN STL CONE PT SET SCR	1

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

**MINI-LINE 520 PNEUMATIC COMPUTER/CONTROLLER,
TYPE FC AND FUNCTION GENERATOR, TYPE FG
VANE PAD SPARE PARTS
KIT NO. 258144-1**




A7017

ITEM	NAME	QUANTITY
1	ADJUSTABLE VANE END	1
2	086 BRASS FLAT WASHER	1
3	1202-00 STN STL S'PROOF L'WASHER	1
4	086 56 BRASS HEX NUT	1

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

**MINI-LINE 520 PNEUMATIC COMPUTER/CONTROLLER,
TYPE FC AND FUNCTION GENERATOR, TYPE FG
VALVE CORE SPARE PARTS
KIT NO. 258145-1**




A7022

ITEM	NAME	QUANTITY
1	VALVE CORE	5
2	VALVE CORE	1

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

MINI-LINE 520 PNEUMATIC COMPUTER/CONTROLLER,
TYPE FC AND FUNCTION GENERATOR, TYPE FG
FILTER SPARE PARTS
KIT NO. 258146-1




A7016

ITEM	NAME	QUANTITY
1	FELT PAD	4
2	W RE MESH D SC	8

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

**MINI-LINE 520 PNEUMATIC COMPUTER/CONTROLLER,
TYPE FC AND FUNCTION GENERATOR, TYPE FG
O-RING SPARE PARTS
KIT NO. 258148-1**




A7024

ITEM	NAME	QUANTITY
1	O R N G	8
2	O R N G	4
3	O R I N G	5
4	O R N G	1

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

**MINI-LINE 520 PNEUMATIC FUNCTION GENERATOR, TYPE FG
CYLINDER SPARE PARTS
KIT NO. 258150-1**




A7015

ITEM	NAME	QUANTITY
1	CYLINDER ASSEMBLY	1
2	TUBE FITTING	1
3	SEAL WASHER	1
4	COMPRESSION CLIP	2

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

**MINI-LINE 520 PNEUMATIC FUNCTION GENERATOR TYPE FG
BELLOWS SPARE PARTS
KIT NO. 258151-1**




A7014

ITEM	NAME	QUANTITY
1	RE LOWS BFAM ASSEMR Y	1
2	OR NG	1
3	112-40x 188 LG HEX SOC HDLS STN STL CONE PT SET SCR	1

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

**MINI-LINE 520 PNEUMATIC FUNCTION GENERATOR, TYPE FG
COVER SPARE PARTS
KIT NO. 258152-1**



A7020

ITEM	NAME	QUANTITY
1	COVER	1
2	SEAL NG CORD	1
3	COVER SCREW	1
4	COVER SCREW	1
5	RETA NING RING	2
6	O R NG GASKET	2

SPECIFY ALL INFORMATION ON NAMEPLATE WHEN ORDERING

23 46 17 04 10 07

— — —